HITACHI

PM


NO. 0752E

RAS-EH18RHLAE/RAC-EH18WHLAE RAS-EH24RHLAE/RAC-EH24WHLAE

SERVICE MANUAL

TECHNICAL INFORMATION

FOR SERVICE PERSONNEL ONLY



REFER TO THE FOUNDATION MANUAL

CONTENTS

	_
SPECIFICATIONS	5
HOW TO USE	9
CONSTRUCTION AND DIMENSIONAL DIAGRAM	42
MAIN PARTS COMPONENT	45
WIRINGDIAGRAM	47
CIRCUIT DIAGRAM	53
PRINTED WIRING BOARD LOCATION DIAGRAM	
BLOCK DIAGRAM	63
BASIC MODE	64
REFRIGERATING CYCLE DIAGRAM	
AUTO SWING FUNCTION	77
DESCRIPTION OF MAIN CIRCUIT OPERATION	88
SERVICE CALL Q & A	96
DISASSEMBLE & ASSEMBLY PROCEDURE	
TROUBLE SHOOTING	106
PARTS LIST AND DIAGRAM	135

SPECIFICATIONS

TYPE -			(WALL TYPE)			
			INDOOR UNIT	OUTDOOR UNIT	INDOOR UNIT	OUTDOOR UNIT
			RAS-EH18RHLAE	RAC-EH18WHLAE	RAS-EH24RHLAE	RAC-EH24WHLAE
POWER SOU	IRCE			1 PHASE 60H	Iz 208 - 230V	
1	TOTAL INPUT	(w)	19	960	2399	
COOLING	TOTAL AMPERES	(A)	8.	70	10	0.40
COOLING	CADACITY	(kW)	5	.2	7.0	
	CAPACITY	(B.T.U./h)	17600 (5700-18600)		24000 (8200-25200)	
TOTAL INPUT	(w)	1930		2210		
UEATING	TOTAL AMPERES	(A)	8.	50	9.60	
HEATING	CADACITY	(kW)	5.5		7.3	
	CAPACITY	(B.T.U./h)	19000 (67	700-20500)	25000 (8300-26500)	
			30.70	33.46	43.30	33.46
		w	(780)	(850)	(1100)	(850)
DINAFAICIONI	s ·		11.07	25.59	11.81	25.59
DIMENSIONS in (mm)		Н	(280)	(650)	(300)	(650)
			9.05	11.73	10.23	11.73
		D	(230)	(298)	(260)	(298)
NET WEIGHT Ib(kg)		17.6 (8)	94.8 (43)	33.1 (15)	97 (44)	

After installation

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT


ROOM AIR CONDITIONER

INDOOR UNIT + OUTDOOR UNIT

APRIL 2021

SAFETY DURING REPAIR WORK

1. In order to disassemble and repair the unit in question, be sure to disconnect the power cord plug from the power outlet before starting the work.



2. If it is necessary to replace any parts, they should be replaced with respective genuine parts for the unit, and the replacement must be effected in correct manner according to the instructions in the Service Manual of the unit.

If the contacts of electrical parts are defective, replace the electrical parts without trying to repair them.

- 3. After completion of repairs, the initial state should be restored.
- 4. Lead wires should be connected and laid as in the initial state.
- 5. Modification of the unit by the user himself should absolutely be prohibited.



- 6. Tools and measuring instruments for use in repairs or inspection should be accurately calibrated in advance.
- 7. In installing the unit having been repaired, be careful to prevent the occurrence of any accident such as electrical shock, leak of current, or bodily injury due to the drop of any part.
- 8. To check the insulation of the unit, measure the insulation resistance between the power cord plug and grounding terminal of the unit. The insulation resistance should be $1M\Omega$ or more as measured by a 500V DC megger.
- The initial location of installation such as window, floor or the other should be checked for being and safe enough to support the repaired unit again.
 If it is found not so strong and safe, the unit should be installed at the initial location after reinforced or at a new location.
- 10. Any inflammable object must not be placed about the location of installation.
- 11. Check the grounding to see whether it is proper or not, and if it is found improper, connect the grounding terminal to the earth.
- 12. If refrigerant gas leaks during repair work, please ensure there is enough ventilation, leaked refrigerant that accumulates in stagnation, rarely causes any igntition when in contact with flame (stove, heater). However it will generate toxic fumes.



13. If refrigerant gas leaks, be sure to repair the leak(s) securely before recharge the unit. Refrigerant (R32) is harmless. However when comes in contact with fire will generate toxic gas.

WORKING STANDARDS FOR PREVENTING BREAKAGE OF SEMICONDUCTORS

Scope

The standards provide for items to be generally observed in carrying and handling semiconductors in relative manufacturers during maintenance and handling thereof. (They apply the same to handling of abnormal goods such as rejected goods being returned).

2. Object parts

- (1) Micro computer
- (2) Integrated circuits (I.C.)
- (3) Field-effective transistor (F.E.T.)
- (4) P.C. boards or the like to which the parts mentioned in (1) and (2) of this paragraph are equipped.

3. Items to be observed in handling

(1) Use a conductive container for carrying and storing of parts. (Even rejected goods should be handled in the same way).




Fig. 1. Conductive container

- (2) When any part is handled uncovered (in counting, packing and the like), the handling person must always use himself as a body earth. (Make yourself a body earth by passing $1M\Omega$ earth resistance through a ring or bracelet).
- (3) Be careful not to touch the parts with your clothing when you hold a part even if a body earth is being taken.
- (4) Be sure to place a part on a metal plate with grounding.
- (5) Be careful not to fail to turn off power when you repair the printed circuit board. At the same time, try to repair the printed circuit board on a grounded metal plate.




Fig. 2. Body Earth

(6) Use a three wire type soldering iron including a grounding wire.




Fig. 3. Grounding of the working table




Fig. 4. Grounding a solder iron

Use a high insulation mode (100V, $10M\Omega$ or higher) when ordinary iron is to be used.

(7) In checking circuits for maintenance, inspection or some others, be careful not to have the test probes of the measuring instrument short circuit a load circuit or the like.

A CAUTION

- 1. Slight flowing noise of refrigerant in the refrigerating cycle is expected to be heard occasionally in quiet or stop operation and it is normal.
- 2. When it thunders near by, it is recommend to stop the operation and to disconnect the power cord plug from the power outlet for safety.
- 3. The room air conditioner does not start automatically after recovery of the electric power failure for preventing fuse blowing. Re-press COOLING button after 3 minutes from when unit stopped.
- 4. If the room air conditioner is stopped by adjusting thermostat, or missoperation, and re-start in a moment, there is occasion that the cooling operation does not start for 3 minutes, it is not abnormal and this is the result of the operation of IC delay circuit. This IC delay circuit ensures that there is no danger of blowing fuse or damaging parts even if operation is restarted accidentally.

SPECIFICATIONS


MODEL		RAS-EH18RHLAE	RAS-EH24RHLAE	RAC-EH18WHLAE	RAC-EH24WHLAE
FAN MOTOR		38W	45W	47	W
FAN MOTOR CAPACITOR		N	10	NO	
FAN MOTOR PROTECTOR		١	10	N	0
COMPRESSOR		١	10	ATD141RDNA8JT	ATD186UKQA9LT6A
COMPRESSOR MOTOR CAP	ACITOR	^	10	N	0
OVERLOAD PROTECTOR		٨	10	N	0
OVERHEAT PROTECTOR		NO YES		ES	
FUSE (for MICROPROCESSOR)		NO 2.0A		DA .	
POWER RELAY		N	10	N	0
POWER SWITCH		N	10	N	0
TEMPORARY SWITCH		Υ	ES	N	0
SERVICE SWITCH		٨	10	YE	ES
TRANSFORMER		N	10	N	0
VARISTOR		NO ZNR		IR	
NOISE SUPPRESSOR		NO YES		ES	
THERMOSTAT		YES(IC) YES(IC)		G(IC)	
REMOTE CONTROL SWITCH (LIQUID CRYSTAL)		Y	ES	N	0
REFRIGERANT	UNIT			52.2oz (1480g)	70.6oz (2000g)
CHARGING VOLUME (Refrigerant R410A)	PIPES (MAX. 82ft (25m)))			Additional 0.007lb/ft (10g/m) after 26.2ft (8m) length	Additional 0.004lb/ft (6g/m) after 26.2ft (8m) length

INDOOR MODEL: RAS-EH18RHLAE


Figure showing the Installation of Indoor


⚠ CAUTION

Height difference" and "Piping length" of Indoor and Outdoor unit are different by Outdoor unit. Please refer to Installation manual of Outdoor unit.



INDOOR MODEL: RAS-EH24RHLAE






There are 6 directions allowed, namely, horizontally perpendicular to the unit, vertically down from right, horizontally out from right, horizontally out to left, horizontally out to right, vertically down from left.

Don't form the piping downward at the left of the unit.

Figure showing the Installation of Indoor

⚠ CAUTION

- The difference in height between the indoor and outdoor unit should be kept max. 49.21ft(15m).
- The connecting pipe, no matter big or small, should all be insulated with insulation pipe and then wrapped with plastic tape. (The insulator will deteriorate if it is not wrapped with tape).



OUTDOOR MODEL: RAC-EH18WHLAE, RAC-EH24WHLAE





Figure showing the Installation of Outdoor Unit.

⚠ CAUTION

In case the pipe length is more than the recommended length for chargeless, add refrigerant R410A as below. Do not exceed the maximum pipe length.

Model	Max. Pipe ft(m)	Chargeless up to ft(m)	Additional R410A lbs/ft(g/m)
RAC-EH18WHLAE	82-1/50(25)	24-61/100(7.5)	0.007(10)
RAC-EH24WHLAE	82-1/50(25)	24-61/100(7.5)	0.004(6)



Important Notice

- Johnson Controls-Hitachi Air Conditioning North America LLC pursues a policy of continuing improvement in design and performance in its products. As such, Johnson Controls-Hitachi Air Conditioning North America LLC. reserves the right to make changes at any time without prior notice.
- Johnson Controls-Hitachi Air Conditioning North America LLC cannot anticipate every possible circumstance that might involve a potential hazard.
- This inverter air conditioning unit is designed for standard air conditioning applications only. Do not use this unit
 for anything other than the purposes for which it was intended.
- The installer and system specialist shall safeguard against leakage in accordance with local codes. The following standards may be applicable, if local regulations are not available. International Organization for Standardization: (ISO 5149 or European Standard, EN 378). No part of this manual may be reproduced in any way without the expressed written consent of Johnson Controls-Hitachi Air Conditioning North America LLC.
- This air conditioning unit will be operated and serviced in the United States of America and comes with a full complement of the appropriate Safety, Danger, and Caution, Warnings.
- If you have questions, please contact your distributor or contractor.
- This manual provides common descriptions, basic and advanced information to maintain and service this air conditioning unit which you operate as well for other models.
- This air conditioning unit has been designed for a specific temperature range. For optimum performance and long life, operate this unit within the range limits.
- This manual should be considered as a permanent part of the air conditioning equipment and should remain with the air conditioning equipment.

Product Inspection upon Arrival

- 1. Upon receiving this product, inspect it for any damages incurred in transit. Claims for damage, either apparent or concealed, should be filed immediately with the shipping company.
- 2. Check the model number, electrical characteristics (power supply, voltage, and frequency rating), and any accessories to determine if they agree with the purchase order.
- 3. The standard utilization for this unit is explained in these instructions. Use of this equipment for purposes other than what it designed for is not recommended.
- 4. Please contact your local agent or contractor as any issues involving installation, performance, or maintenance arise. Liability does not cover defects originating from unauthorized modifications performed by a customer without the written consent of Johnson Controls-Hitachi Air Conditioning North America LLC Performing any mechanical alterations on this product without the consent of the manufacturer will render your warranty null and void.

California Proposition 65



Proposition 65: This product contains chemicals known to the state of California to cause cancer, birth defects, and other reproductive harm. For more information, go to www.P65Warnings.ca.gov



SAFETY PRECAUTION

- Please read the "Safety Precaution" carefully before operating the unit to ensure correct usage of the unit.
- To prevent personal injury or property damage, read this section carefully before you use this product, and be sure to comply with the following safety precautions. Incorrect operation due to failure to follow the instructions may cause harm or damage, the seriousness of which is classified as follows:

WARNING

This mark warns of death or serious injury.

A CAUTION

This mark warns of injury or damage to property.



This mark denotes an action that is PROHIBITED.



A

R

N

N

G

This mark denotes an action that is COMPULSORY.

Please keep this manual after reading.

WARNING

- Please use ground wiring. Connect the power supply and the ground wiring to the terminals in the electrical box. Ground wiring must be securely connected. Use a GFCI (Ground Fault Circuit Interrupter). Failure to use a GFCI can result in electric shock or fire.
- Be sure to use the specified piping set for R410A. Otherwise, this may result in broken copper pipes or faults.
- Should abnormal situation arises (like burning smell), please stop operating the unit and turn off the circuit breaker. Contact your agent. Fault, short circuit or fire may occur if you continue to operate the unit under abnormal situation.
- Please contact your agent for maintenance. Improper self maintenance may cause electric shock and fire.
- Please contact your agent if you need to remove and reinstall the unit. Electric shock or fire may occur if you remove and reinstall the unit yourself improperly.
- If the supply cord is damaged, it must be replaced by the special cord obtainable at authorized service/ parts centers.
- Do not insert a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury. Before cleaning, be sure to stop the operation and turn the breaker OFF.
- Do not use any conductor as fuse wire, this could cause fatal accident.
- During thunder storm, disconnect and turn off the circuit breaker.
- Do not reconstruct the unit.
 - Water leakage, fault, short circuit or fire may occur if you reconstruct the unit by yourself.
- Please ask your sales agent or qualified technician for the installation of your unit. Water leakage, short circuit or fire may occur if you install the unit by yourself.
- Spray cans and other combustibles should not be located within a meter 3.28ft(1m) of the air outlets of both indoor and outdoor units. As a spray can's internal pressure can be increased by hot air, a rupture may result.



CAUTION



0

- A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists.
- Do not install near location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it.
- Please ensure a smooth flow of condensate when installing the condensate hose.
- Do not install the indoor unit in a machine shop or kitchen where vapor from oil or its mist flows to the indoor unit. The oil will deposit on the heat exchanger, thereby reducing the indoor unit performance and may deform and in the worst case, break the plastic parts of the indoor unit.

PRECAUTIONS DURING OPERATION

• The product shall be operated under the manufacturer specification and not for any other intended use.





- Do not attempt to operate the unit with wet hands, this could cause fatal accident.
- When operating the unit with burning equipments, regularly ventilate the room to avoid insufficient oxygen.





- Do not direct the cool air coming out from the air-conditioner panel to face household heating apparatus as this may affect the working of apparatus such as the electric kettle, oven etc.
- Please ensure that outdoor mounting frame is always stable, firm and without defect. If not, the outdoor unit may collapse and cause danger.





- Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.
- Do not use any aerosol or hair sprays near the indoor unit. This chemical can adhere on heat exchanger fin and block the flow of condensate to the condensate pan. Condensate might drip on the fan and cause droplets to occasionally drip from the indoor unit.





- Please switch off the unit and turn off the circuit breaker during cleaning, the high-speed fan inside the unit may cause danger.
- Turn off the circuit breaker if the unit is not to be operated for a long period.





- Do not climb on the outdoor unit or put objects on it.
- Do not put water container (like vase) on the indoor unit to avoid water dripping into the unit. Dripping water will damage the insulator inside the unit and cause a short circuit.






- Do not place plants directly under the air flow as it is bad for the plants.
- When operating the unit with the door and windows opened, (the room humidity is always above 80%) and with the louver facing down or moving automatically for a long period of time, condensate will condense on the louver and drips down occasionally. This will wet your furniture. Therefore, do not operate under such condition for a long time.
- If the amount of heat in the room is above the cooling or heating capability of the unit (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
 - Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.



NAMES AND FUNCTIONS OF EACH PART

INDOOR UNIT



Pre-filter

To prevent dust from coming into the indoor unit.

Front panel

Indoor unit indicators

LED light shows the operating mode.

Horizontal deflector • Vertical deflector (Air Outlet)




Remote controller

Send out operation signal to the indoor unit. So as to operate the whole unit.

Please refer to the Remote Manual provided for functions and operation details.

OUTDOOR UNIT



DRAIN PIPE

Condensed water drain to outside.

CONNECTING CORD AND INSULATION PIPE FOR PIPING

AIR INLET (BACK, LEFT SIDE)

AIR OUTLET


A CAUTION

 When heating operation, drain or defrosted water flows out from outdoor unit. Don't close drain outlet portion in chilly area so as not to freeze these.

MODEL NAME AND DIMENSIONS

MODEL	WIDTH in(mm)	HEIGHT in(mm)	DEPTH in(mm)
RAS-EH18RHLAE	30.70"(780)	11.07" (280)	9.05" (230)
RAC-EH18WHLAE	33.46"(850)	25.59" (650)	11.73" (298)

INDOOR UNIT INDICATORS MODEL RAS-EH18RHLAE



TEMPORARY SWITCH button


TEMPORARY SWITCH

Use this switch to start and stop when the remote controller does not work.

- By pressing the temporary switch, the operation is done in automatic mode.
- When the operation is done using the temporary switch after the power source is turned off and turn on again, the operation is done in automatic mode.

NAMES AND FUNCTIONS OF EACH PART

INDOOR UNIT



Pre-fi Iter


To prevent dust from coming into the indoor unit.

Front panel

Indoor unit indicators

LED light shows the operating mode.

Horizontal deflector • Vertical deflector (Air Outlet)




Remote controller

Send out operation signal to the indoor unit. So as to operate the whole unit.

Please refer to the Remote Manual provided for functions and operation details.

OUTDOOR UNIT



DRAIN PIPE

Condensed water drain to outside.

CONNECTING CORD AND INSULATION PIPE FOR PIPING

AIR INLET (BACK, LEFT SIDE)

AIR OUTLET

A CAUTION


 When heating operation, drain or defrosted water flows out from outdoor unit. Don't close drain outlet portion in chilly area so as not to freeze these.

MODEL NAME AND DIMENSIONS

MODEL	WIDTH in(mm)	HEIGHT in(mm)	DEPTH in(mm)
RAS-EH24RHLAE	43.31"(1100)	11.81" (300)	10.24" (260)
RAC-EH24WHLAE	33.46"(850)	25.59" (650)	11.73" (298)

INDOOR UNIT INDICATORS

MODEL RAS-EH24RHLAE



OPERATION LED

This LED lights during operation.

The OPERATION LED fl ashes/dimming in the following cases during heating.

(1) 1) Duri preheating

For about 2-3 minutes after starting up.

(2) 2) Duri defrosting

Defrosting is performed about once every one hour when frost forms on the heat exchanger of the outdoor unit, for 5–10 minutes each time.


TIMER LED

This LED lights up when the timer is working.

FROST WASH LED

This LED lights when the Frost Wash function is in operation. If the auto Frost Wash function is canceled and operation is stopped, when the device is operated for a total of about 42 hours, the Frost Wash LED blinks to indicate that it is time to operate the manual Frost Wash function. (not applicable for Multi split connection)

OPERATION INDICATOR



TEMPORARY SWITCH

Use this switch to start and stop when the remote controller does not work. [Use non-conductor stick (example toothpick)]

- By pressing the temporary switch, the operation is done in automatic operation mode.
- When the operation is done using the temporary switch after the power source is turned off and turn on again, the operation is done in automatic mode.


Suitable Room Temperature



A Warning

Freezing temperature is bad for health and a waste of electric power.

Install curtain or blinds



It is possible to reduce heat entering the room through windows.

Ventilation

A Caution


Do not close the room for a long period of time. Occasionally open the door and windows

to allow the entrance of fresh air.



Effective Usage Of Timer

At night, please use the "OFF or ON timer or SLEEP timer operation mode", together with your wake up time in the morning. This will enable you to enjoy a comfortable room temperature. Please use the timer effectively.



Do Not Forget To Clean The Pre-Filter

Dusty air filter will reduce the air volume and the cooling efficiency. To prevent from wasting electric energy, please clean the filter every 2 weeks.




Please Adjust Suitable Temperature For Baby And Children

Please pay attention to the room temperature and air flow direction when operating the unit for baby, children and old folks who have difficulty in movement.

The Air Conditioner And The Heat Source In The Room


A Caution

If the amount of heat in the room is above the cooling capability of the air conditioner (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.



Not Operating For A Long Time


When the indoor unit is not to be used for a long period of time, please switch off the power from the main unit. If the power from main unit remains "ON", the indoor unit still consumes about 3W in the operation control circuit even if it is in "OFF" mode.



When Lightning Occurs

A Warning


To protect the whole unit during lightning, please stop operating the unit.



Interference From Electrical Products

A Caution


To avoid noise interference, please place the indoor unit and its remote controller at least 3.28ft (1m) away from electrical products.



AIRFLOW LOUVERS ADJUSTMENTS

Adjustment of the conditioned air to the left and right.

Hold the second vertical louver of each set of vertical louver from right as shown in the figure and adjust the conditioned air to the left or right.



A WARNING

Do not insert a finger, a rod or other objects into the air outlet or inlet as the fan is rotating at a high speed, it will cause injury. Before any cleaning or adjusting the louvers, be sure to switch OFF the operation.

ATTACHING THE AIR PURIFYING FILTERS (RAS-EH18RHLAE)

A CAUTION

Before cleaning, stop operation and switch off the power supply.




Open the front panel

 Pull up the front panel by holding it at both sides with both hands.




Remove the Pre-filter


 Push upward to release the clasps and pull out the Pre-filter.



Attaching the air purifying filters

- Attach the air purifying filters to the C-case by gently compress its both sides and release after insertion into filter frame.
- Bring the C-case to the back side of the pre-filter. Insert it claws on left and right to the C-case fixing slot securely. Honeycomb surface shall be on the front side and flat surface shall be on the back side when insert (only for the purifying filter with a flat surface).






A CAUTION

Do not bend the air purifying filter as it may cause damage to the structure.

Please do not smell direct from source of filter.








Attach the Pre-filters

- Attach the Pre-filters by ensuring that the surface written "FRONT" is facing front.
- After attaching the Pre-filters, push the front panel at three arrow portions as shown in figure and close it.



NOTE


- In case of removing the air purifying filters, please follow the above procedures.
- The cooling capacity is slightly weakened and the cooling speed becomes slower when the air purifying filters are used. So, set the fan speed to "HIGH" when using it in this condition.
- Air purifying filters are not washable. It is recommended to use vacuum to clean it. It can be use for 1 year time. Type number for this air purifying filter is <SPX-CFH22AC25>. Please use this number for ordering when you want to renew it. Part can be purchased from an authorized service parts centers.

ATTACHING THE AIR PURIFYING FILTERS (RAS-EH24RHLAE)



Open the front panel


 Pull up the front panel by holding it at both sides with both hands.





Remove the Prefilter


 Push upward to release the clasps and pull out the Pre-filter.






Attaching the air purifying filters

• Attach the air purifying filters to the frame by gently compress its both sides and release after insertion to Pre-filter frame. Flat surface (Back side)





Honeycomb surface (Front side)




CAUTION

Do not bend the air purifying filter as it may cause damage to the structure.

Please do not smell direct from source of filter.








Attach the Prefilters

- Attach the Pre-filters by ensuring that the surface
- written "FRONT" is facingront. After attaching the Pre-filters, push the front panel at three arrow portions as shown in figure and close it.



NOTE

- In case of removing the air purifying filters, please follow the above procedures.
- The cooling capacity is slightly weakened and the cooling speed becomes slower when the air purifying filters are used. So, set the fan speed to "HIGH" when using it in this condition.
- Air purifying filters are not washable. It is recommended to use vacuum to clean it. It can be use for 1 year time. Type number for this air purifying filter is <SPX-CFH22AC25>. Please use this number for ordering when you want to renew it. Part can be purchased from an authorized service parts centers.



MAINTENANCE

A CAUTION

Before cleaning, stop operation and switch off the power supply.

1. PRE-FILTER III


Clean the Pre-filter, as it removes dust inside the room. In case the Pre-filter is full of dust, the air flow will decrease and the cooling capacity will be reduced. Further, noise may occur. Be sure to clean the Pre-filter following the procedure below.

PROCEDURE




Open the front panel and remove the Pre-filter

 Gently lift and remove the air purifying filters from the air purifying filter frame.



Vacuum dust from the Pre-filter and air purifying filter using vacuum cleaner. If there is too much dust, rinse under running tap water and gently brush it with soft bristle brush. Allow filters to dry in shade.







- Re-insert the air purifying filter to the filter frame.
 Set the Pre-filter with "FRONT" mark facing front, and slot them into the original state.
- After attaching the Pre-filters, push the front panel at three arrow portions as shown in figure and close it.




A CAUTION

- Do not operate the air conditioner without Pre-filter. Dust may enter the air conditioner and fault may occur.
- Do not wash with hot water at more than 104°F(40°C). The Pre-filters may shrink.
- When washing it, shake off moisture completely and dry it in the shade; do not expose it directly to the sun. The Pre-filters may shrink.
- Do not use detergent on the Pre-filter as some detergent may deteriorate the Pre-filter electrostatic performance.

CLEANING OF FRONT PANEL


- Remove the front panel and wash with clean water. Wash it with a soft sponge. After using mild detergent, wash thoroughly with clean water.
- When front panel is not removed, wipe it with a soft dry cloth. Wipe the remote controller thoroughly with a soft dry cloth.
- Wipe the water thoroughly. If water remains at LEDs or signal receiver of indoor unit, it causes trouble.

Method of removing the front panel. Be sure to hold the front panel with both hands to detach and reattach it.






Removing the Front Panel



Reattaching the Front Panel



- 1. Push the end of the right-side arm outward to release the right tab.
- 2. Move the left-side arm outward to release the left tab and then pull the panel towards you.
- 1. Insert the shaft of the left arm along the step on the unit into the hole.
- 2. Securely insert the shaft of the right arm along the step on the unit into the hole.
- 3. Make sure that the front panel is securely attached an then close the front panel.

A CAUTION

• Never use hot water (above 104°F(40°C)), benzine, gasoline, acid, thinner or a brush, because they will damage the plastic surface and the coating.



▲ CAUTION

Please use ground wiring.

Do not place the ground wiring near water or gas pipes, lightning-conductor, or the ground wiring of telephone. Improper installation of ground wiring may cause electric shock.



...

 A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists.

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

Green-and-yellow Earth/Ground
White : Neutral
Black : Line

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured green-and-yellow must be connected to the terminal in the plug which is marked with the letter E or by the earth symbol (1) or coloured green or green-and-yellow.

The wire which is coloured white must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured black must be connected to the terminal which is marked with the letter L or coloured red.

NOTE


If the supply cord is damaged, it must be replaced with the new cord obtainable at authorized service parts centers.

A CAUTION

Cleaning and maintenance must be carried out only by qualified service personnel. Before cleaning, stop operation and switch off the power supply.

REGULAR INSPECTION

PLEASE CHECK THE FOLLOWING POINTS BY QUALIFIED SERVICE PERSONNEL EITHER EVERY HALF YEARLY OR YEARLY. CONTACT YOUR SALES AGENT OR SERVICE SHOP.



Is the ground wiring disconnected or broken?





Is the mounting frame seriously affected by rust and is the outdoor unit tilted or unstable?

WHEN ASKING FOR SERVICE, CHECK THE FOLLOWING POINTS.

CONDITION	CHECK THE FOLLOWING POINTS
If the remote controller is not transmitting a signal. Remote controller display is dim or blank.)	 Do the batteries need replacement? Is the polarity of the inserted batteries correct?
When it does not operate	 Is the fuse blown? Is the power supply in normal condition? Is the circuit breaker "ON"? Is the setting of operation mode different from other indoor units?
When it does not cool well When it does not hot well	 Is the pre-filter blocked with dust? Does sunlight fall directly on the outdoor unit? Is the airflow of the outdoor unit obstructed? Are the doors or windows opened, or is there any source of heat in the room? Is the set temperature suitable? Are the air inlets or air outlets of indoor and outdoor units blocked? Is the fan speed "LOW" or "SILENT"?



Notes

- In quiet operation or stopping the operation, the following phenomena may occassionally occur, but they are not abnormal for the operation.
 - (1) Slight flowing noise of refrigerant in the refrigerating cycle.
 - (2) Slight rubbing noise from the fan casing which is cooled and then gradually warmed as operation stops.
- The odor will possibly be emitted from the room air conditioner because the various odor, emitted by smoke, foodstuffs, cosmetics and so on, sticks to it. So the pre-filter and the evaporator regularly must be cleaned to reduce the odor.
- Please contact your sales agent immediately if the air conditioner still fails to operate normally after the above inspections. Inform your agent of the model of your unit, production number, date of installation. Please also inform him regarding the fault.
- Power supply shall be connected at the rated voltage, otherwise the unit will be broken or could not reach the specified capacity.

NOTE:

 If the supply cord is damaged, it must be replaced with the new cord obtainable at authorized service parts centers.

Please note:

On switching on the equipment, particularly when the room light is dimmed, a slight brightness fluctuation may occur. This is of no consequence.

The conditions of the local Power Supply Companies are to be observed.

Note

 Avoid using the room air conditioner for cooling operation when the outside temperature is below the minimum recommended temperature.

The recommended maximum and minimum operating temperatures of the hot and cold sides should be as below:

Single Split model connection (RAC-EH** series)

		Cooling		Hea	ıting
		Minimum Maximum		ximum Minimum Maximun	
Indoor	Dry bulb	70°F (21°C)	90°F (32°C)	68°F (20°C)	81°F (27°C)
	Wet bulb	59°F (15°C)	73°F (23°C)	_	_
Outdoor	Dry bulb	-0.4°F (-18°C)	114.8°F (46°C)	-0.4°F (-18°C)	75.2°F (24°C)
	Wet bulb	_	_		_

Multi Split model connection (RAM-SH** series)

		Coc	oling	Heating	
		Minimum Maximum		Minimum Maximum	
Indoor	Dry bulb	70°F (21°C)	90°F (32°C)	68°F (20°C)	81°F (27°C)
	Wet bulb	59°F (15°C)	73°F (23°C)	_	_
Outdoor	Dry bulb	14°F (-10°C)	114.8°F (46°C)	-4°F (- 20°C)	75.2°F (24°C)
	Wet bulb	_	_	_	_

EMO	
	- 13


PREPARATION BEFORE OPERATION

When using the remote controller, if there is no response from the air conditioning unit and/or the display has faded and dimmed, the batteries in the remote control need to be removed and replaced with a new set.

To set the batteries


- 1. Slide the cover to take it off.
- Set two dry batteries type AAA/LR03 (alkaline).
 The batteries must be placed in the position of "+" and "-" polar.
- 3. Reinstall the battery cover.
- 4. Press Reset button.

Push and pull to the direction of arrow



■ To mount the remote controller holder to the wall

- 1. Choose a place from where the signals can reach the unit.
- 2. Mount the remote controller holder to a wall, a pillar or similar location with the provided screws.
- 3. Place the remote controller in the remote controller holder.



NOTES


If you replace the batteries, or after pressing 'Reset' button, the temperature display will return to °F. Follow 'Temperature Switching' instruction to change to °C.

A CAUTION

- 1. Do not mix up new and old batteries or different kind of batteries together.
- 2. Take out the batteries when you do not use the remote controller for 2 or 3 months.
- 3. Use high quality and high performance AAA batteries to avoid short operating life and electrolytes leakage.
- 4. After batteries are replaced or when an operation is abnormal, press 'Reset' button using a pen point.

NAMES AND FUNCTIONS OF REMOTE CONTROLLER

This remote controller controls the operation and timer setting of the room air conditioner. The operating range of the remote control from the indoor unit is 23feet (approx. 7m). If inverter lamp is used, the range may become shorter.



Precautions for Use

- Do not place the remote controller in the following places.
 - Under direct sunlight.
 - In the vicinity of a heater.
- Handle the remote controller carefully. Do not drop it on the floor, and protect it from water.
- Once the outdoor unit stops, it will not restart for about 3 minutes (unless you turn the power switch off and on or unplug the power cord and plug it in again).
 - This is to protect the room air conditioner and does not indicate a failure.
- If you press the Mode button during operation, the room air conditioner may stop for about 3 minutes for protection.

Temperature Switching


The default temperature display for this model is Fahrenheit (°F).

To switch the temperature display from Celsius to Fahrenheit


- Release O Reset button while pressing until




(3) °F sign appears on the screen. The temperature display has switched to Fahrenheit.




- To switch the temperature display from Fahrenheit to Celsius
- Press and hold O Reset + button for 3s. Release
- Release O Reset button while pressing nutil LCD shows Full Segment display.





(3) °C sign appears on the screen. The temperature display has switched to Celsius.



NOTE

• Temperature switching will be initialized after user press 'Reset' button or replace the batteries.


VARIOUS FUNCTIONS

■ Auto Restart Control

- After recovering from power cut, the room air conditioner will automatically restored with operation mode and airflow operation set previously.
 - (This is because operation is not stopped by the remote controller)
- If you do not require Auto Restart Control, please contact your local sales agent.
- Auto Restart Control is not available when the Timer or Sleep Timer is set.


AUTOMATIC OPERATION

The room air conditioner automatically selects the mode, i.e. HEAT or COOL mode depending on the current room temperature. The selected operation mode will change as the room temperature changes. However, the operation mode does not change when the indoor unit is connected to a Multi Type outdoor unit.



HEATING OPERATION

- Use the room air conditioner for heating when the outdoor temperature lies within the range stated in Indoor Unit Operation Manual.
 - When the temperature is too warm, the heating operation may not work in order to protect the room air conditioner.
- To maintain the reliability of the room air conditioner, please operate when outdoor temperature is above minimum operating range.



Defrosting

Defrosting will be performed about $5 \sim 10$ minutes for every 1 hour when frost forms on the heat exchanger of the outdoor unit.

During the defrost operation, the operation LED blinks in a cycle of 2 seconds on and 1 second off. The maximum time for defrosting is 20 minutes.


However, if the indoor is connected to a multi type outdoor unit, the maximum time for defrosting is 15 minutes.

(If the piping length used is longer than usual, frost is likely to form.)

COOLING OPERATION


Use the room air conditioner for cooling when the outdoor temperature lies within the range stated in Indoor Unit Operation Manual.

If indoors humidity is very high (80%), some dew may form on the air outlet grille of the indoor unit.



DEHUMIDIFYING OPERATION

Use the room air conditioner for dehumidifying when the room temperature is over 60°F (16°C). When it is under 59°F (15°C), the dehumidifying function does not work.




NOTE

- When the room temperature is higher than the set temperature: The device will dehumidify the room, reducing
 the room temperature to the preset level.
 When the room temperature is lower than the set temperature, Dehumidifying will be performed at the
 temperature setting slightly lower than the actual room temperature, regardless of the temperature setting.
- The preset room temperature may not be reached depending on the number of people present in the room or other room conditions.

FAN OPERATION

Use the unit as an air circulator.




TIMER SETTING

ON Timer and OFF Timer are available.


Timer Off setting

- Set the timer to power off the air conditioner.
- Timer setting will change according to the sequence below when Timer Off button is pressed.




Timer On setting

- Set the timer to power on the air conditioner
- Timer setting will change according to the sequence below when Timer On button is pressed.



Operation stops at set time.




Operation starts at set time and temperature.



POWERFUL OPERATION

- By pressing the (POWERFUL) button during HEATING, DEHUMIDIFYING, COOLING, FAN or AUTOMATIC operation, the air conditioner operates at maximum power.
- During POWERFUL operation, cooler or warmer air flow will be blown out from the indoor unit for COOLING or HEATING operation respectively.



Press the Powerful (POWERFUL) button during operation.

• " \square " is displayed on the LCD.

POWERFUL operation ends in 20 minutes. Then, the system will automatically return to the previous settings.

 During POWERFUL operation, cooler or warmer air flow will be blown out from the indoor unit for COOLING and HEATING operation respectively.



STAR


- Press the \bigcirc (ON/OFF) button or
- Press the P
 - " 🚇 " will disappear from the display.

NOTE

- When ECO mode is selected, POWERFUL operation is cancelled.
- During POWERFUL operation, capacity of the air conditioner will not increase if the air conditioner is already running at maximum capacity.
- After auto restart, POWERFUL operation is cancelled and unit will operate with previous operation.
- For Multi-model connections, POWERFUL operation may not function depending on operation conditions.

LEAVE HOME(LH) OPERATION

Use this function to prevent the room temperature from falling too much when no one is attended at home. The default setting is $50^{\circ}F$ ($10^{\circ}C$) and the temperature setting is between $50^{\circ} \sim 60^{\circ}F$ ($10^{\circ} \sim 16^{\circ}C$).



1) Press the (LEAVE HOME) button to activate the function.

Room temperature is set at 50°F (10°C) and HEATING operation starts.

② Set the desired room temperature using (TEMP) button. Temperature range can be set between 50°F (10°C) and 60°F (16°C).

", ", ", " LH ", "SET TEMPERATURE" is displayed on the LCD.



START

Press the On/OFF (ON/OFF) button, or

Press the Mode (MODE) button, or

• Press the (LEAVE HOME) button again.


LH will disappear from the display.


NOTE

• During Leave Home operation, fan speed and horizontal air deflector position cannot be changed.

CLEAN (ONE TOUCH CLEAN) OPERATION (For Multi-model connection)

Use this function to dry the heat exchanger of the indoor unit to prevent formation of mildew.






Press the (FROST WASH/CLEAN) button when unit is in Standby mode.

Total time taken for One Touch Clean operation is 60 minutes. One Touch Clean operation consists of HEATING and DRYING operation.

During One Touch Clean, operation LED lights up and "L" is displayed on the LCD.




- When CLEAN operation has finished, the unit will enter Standby mode automatically.
- If OFF TIMER or ON TIMER is pre-set, there is a need to cancel those timers before operating CLEAN function.
- For Multi-model connection, when pressing the (FROST WASH/CLEAN), operation is limited to FAN operation only.
- For Multi-model connection, when one unit is operating CLEAN operation, the other units can operate COOLING, DEHUMIDIFYING & FAN operation.
 - However, when other units need to operate HEATING operation, the air conditioners will be in Standby mode. After CLEAN operation has finished, HEATING operation will start.

FROST WASH OPERATION (For single model connection)


- The dust and dirt adhering to indoor heat exchanger which is the cause of the smell. They are washed away by freezing and thawing of the heat exchanger.
- Frost Wash function can work when the outdoor temperature is 34° to 109°F (1° to 43°C) and indoor humidity is 30% to 70%.

Frost Wash



- " lamp on the indoor unit lights up during Frost Wash operation.
- If you want to stop Frost Wash operation, press the On/Off (ON/OFF) button once.
- When pressing the button such as cooling during Frost Wash operation, Frost Wash operation is discontinued and start the cooling operation after about 3 minutes.
- In order to protect the product, Frost Wash function cannot be carried out again for about 60 minutes after Frost Wash operation is completed.

■ Frost Wash (Manual mode)




Precautions for Use

- Do not open windows or doors during frost wash operation. Water will condense on the air deflector and drips down occasionally. This will wet your furniture.
- Do not open or remove the front panel during Frost Wash operation. It may cause injury or malfunction.
- Frost Wash operation does not wash away all dust and dirt.
- Hissing, fizzy or squeaking noise may generate during Frost Wash operation.
- If the air conditioner is continuously running, Frost Wash function is not effective.
- During Frost Wash operation, if power is turned off and then power is restored, Frost Wash function will not restart.
- After turning on the power, please wait a moment if you want to start Frost Wash.

ECO OPERATION


ECO operation is an energy saving function by changing set temperature automatically and limiting the maximum power consumption value.



- ECO function may not be effective when power consumption is low.
- By pressing the Powerful (POWERFUL) button, ECO operation is cancelled.
- After auto restart, ECO operation is cancelled and unit will operate with previous operation.

SILENT OPERATION

By pressing the (SILENT) button during AUTO, HEATING, DEHUMIDIFYING, COOLING or FAN operation, fan speed will change to silent fan speed.





CANCEL

- When 📆 button is pressed,
- " [" will be displayed on the LCD.
- Fan speed will be in silent .

operation starts.

- Press the On/Off° (ON/OFF) button, or
- Press the (SILENT) button once again or
- Press the Fan Speed (FAN SPEED) button.


 Fan speed will return to the previous speed before SILENT

When SILENT operation stops, " will disappear from the LCD

- When POWERFUL operation is selected, SILENT operation will be cancelled. Fan speed will return to the previous speed before SILENT operation.
- After unit auto restart, SILENT operation is cancelled. Fan speed will return to the previous speed before SILENT operation.
- During any operations with silent fan speed , if user press (SILENT) button, the fan speed will not change.

SLEEP TIMER SETTING

By pressing the (SLEEP) button during AUTO, HEATING, DEHUMIDIFYING, COOLING or FAN operation, the unit shifts the room temperature and reduces the fan speed.



CANCEL

Mode	Indication		
Sleep timer	1 hour → 2 hours → 3 hours → 7 hours — Sleep timer off ◆		

designated number of hours.

When (SLEEP) button is pressed,

- Timer information will be displayed on the LCD.
- The timer LED lights up and a beep sound is emitted from the indoor unit.

During Sleep Timer, the unit will continue working for the

Press the On/Off (ON/OFF) button.
 Room air conditioner will enter Standby mode.
 Press the (SLEEP) button again until timer cancels.
 "and number of hours will disappear from the LCD.
 The timer LED turns off and a beep sound is emitted from the indoor unit.

- If you set SLEEP timer while ON TIMER or OFF TIMER has been pre-set, the sleep timer becomes effective instead ON TIMER or OFF TIMER.
- The indoor fan speed of air conditioner does not change even when fan speed button is pressed.

ADJUSTING THE AIRFLOW DIRECTION



Adjust the airflow upward and downward

The horizontal air deflector is automatically set to the specific angle that is suitable for each operation. The deflector can swing up and down and set to Up/Down


desired angle by pressing $\left\lceil \frac{P_{LZ}}{P_{LZ}} \right\rceil$ (UP/DOWN) button.

and it will start moving after several seconds (about 6 seconds).

• When the operation is stopped, the horizontal air deflector moves and stops at the position where the air outlet closes.



 In "Cooling" operation, do not keep the horizontal air deflector swinging for a long time. Some dew may be formed on the horizontal air deflector and may drop from it.




CONSTRUCTION AND DIMENSIONAL DIAGRAM FOR INDOOR

INDOOR UNIT

MODEL RAS-EH18PHLAE


Unit: Inch (mm)



CONSTRUCTION AND DIMENSIONAL DIAGRAM

INDOOR UNIT


MODEL RAS-EH24PHLAE



CONSTRUCTION AND DIMENSIONAL DIAGRAM FOR OUTDOOR

OUTDOOR UNIT

MODEL: RAC-EH18WHLAE / RAC-EH24WHLAE



MAIN PARTS COMPONENT

THERMOSTAT

Thermostat Specifications

MODEL		RAS-EH18RHLAE, RAS-EH24RHLAE	
THERMOSTAT MODEL		IC	
OPERATION		COOL	
	INDICATION	ON	16.7 (62.1)
	16	OFF	16.0 (60.8)
TEMPERATURE °C	INDICATION 24	ON	24.7 (76.5)
		OFF	24.0 (75.2)
	INDICATION 32	ON	32.7 (90.9)
		OFF	32.0 (89.6)

FAN MOTOR

Fan Motor Specifications

MODEL		RAS-EH18RHLAE	RAS-EH24RHLAE	RAC-EH18WHLAE RAC-EH24WHLAE
RATED VOLTA	MGE	DC340V	DC340V	DC120 - 380V
OUTPUT		38 W	38 W 38 W	
CONNECTION		DC263~400Vo RED 0V° BLK WHT DC13.5~16.5V° YEL FG o BLU (Control circuit built in)	DC263~400V o RED 0V o BLK 0V O WHT DC13.5~16.5V O YEL DC0~6.5V O BLU FG O BLU (Control circuit built in)	M M M M M M M M M M M M M M M M M M M
RESISTANCE VALUE (Ω)	20°C (68°F)		0	38.2 ± 3.9

BLU : BLUE YEL : YELLOW BRN : BROWN WHT : WHITE GRY : GRAY ORN : ORANGE GRN : GREEN RED : RED

BLK : BLACK

COMPRESSOR MOTOR

Compressor Motor Specifications

MODEL		RAC-EH18WHLAE	RAC-EH24WHLAE	
COMPRESSOR MODEL		ATD141RDNA8JT	ATD186UKQA9LT6A	
PHASE		SINGLE		
RATED VOLTAGE		AC 220V - 240V		
RATED FREQUENCY		50/60 Hz		
POLE NUMBER		4 pole	6 Pole	
CONNECTION		YELLOW Ø	WHITE M M RED	
RESISTANCE VALUE	20°C (68°F)	2M = 1.310 ±7%	2M = 1.354 ±7%	
(Ω)	75°C (167°F)			

▲ CAUTION


When the Air Conditioner has been operated for a long time with the capillary tubes clogged or crushed or with too little refrigerant, check the color of the refrigerant oil inside the compressor. If the color has been changed conspicuously, replace the compressor.

WIRING DIAGRAM

MODEL RAS-EH18RHLAE


INDOOR UNIT

BLU : BLUE YEL : YELLOW BRN : BROWN WHT : WHITE GRY : GRAY ORN : ORANGE GRN : GREEN RED : RED BLK : BLACK PNK : PINK VIO : VIOLET IVO : IVORY



MODEL RAC-EH18WHLAE

OUTDOOR UNIT




- 47 -

WIRING DIAGRAM

MODEL RAS-EH24RHLAE


INDOOR UNIT

YELLOW BLU BLUE YEL BRN **BROWN** WHT WHITE **GRY GRAY** ORN **ORANGE** GRN **GREEN** RED RED **BLK BLACK** PNK PINK VIO **VIOLET** IVO **IVORY**



MODEL RAC-EH24WHLAE


OUTDOOR UNIT




- 49 -


CIRCUIT DIAGRAM

Remote Controller



CIRCUIT DIAGRAM





- 55 -


| N973 | 24 | 5% | 1/10 | D911 | ISSJ55W| D915 | ISSJ55W| D915 | ISSJ55W| D915 | ISSJ55W| D916 | ISSJ55W| D916

PRINTED BOARD LOCATION DIAGRAM

MODEL: RAS-EH18RHLAE

MAIN P.W.B

Marking on P.W.B



RECEIVING P.W.B Marking on P.W.B



SENSOR P.W.B Marking on P.W.B




PRINTED BOARD LOCATION DIAGRAM


MODEL: RAS-EH24RHLAE

MAIN P.W.B


Marking on P.W.B




RECEIVING P.W.B Marking on P.W.B




SENSOR P.W.B Marking on P.W.B



MAIN PWB MODEL RAC-EH18WHLAE RAC-EH24WHLAE







Top side

Bottom side

HIC PWB




Top side




Bottom side

BLOCK DIAGRAM



BASIC MODE




Basic Cooling Operation Room temperature Temperature set for cooling and dehumiditying (value set by remote control [1]) Fan speed set to "auto" Start/stop switch Thermo judgment Indoor fair Silent Ultra-Lo Operation lamp 1min. NOTE (9) CMAX NOTE (5) Rating 3000

Notes:


- (1) Condition for entering into Cool Dashed mode. When fan set to "Hi" or "Auto and when the compressor speed (P section) due to temperature difference between setting temperature (including the correction shift only) and room temperature is CMAX or higher.
- (2) Cool Dashed will release when i) a maximum 25 minutes is lapsed and ii) room temperature is lower than set temperature -3°C (thermo off) and iii) when room temperature has achieved setting temperature -1°C then maximum Cool Dashed time will be revised to 20 minutes. And iv) indoor fan is set to Lo and Med fan mode and v) change operation mode.
- (3) During Cool Dashed operation, thermo off temperature is set temperature (with shift value) -3°C. After thermo off, operation continue in Fuzzy control mode.

15sec.

- (4) Compressor minimum "ON" time and "OFF" time is 3 minutes.
- (5) During normal cooling mode, compressor maximum rpm CMAX will maintain for 60 minutes if indoor temperature is lower than CLMXTP. No time constrain if indoor temperature is higher than CLMXTP.
- (6) When fan is set to "Hi", compressor rpm will be limited to CSTD.
- (7) When fan is set to "Med", compressor rpm will be limited to CJKMAX.
- (8) When fan is set to "Lo", compressor rpm will be limited to CBEMAX.
- (9) During Cool Dashed, when room temperature reaches set temperature -1°C compressor rpm is actual rpm x DWNRATEC.



Cooling Powerful Operation



Notes:

- (1) Pressing the "POWERFUL" button will reduce the temperature setting by PWSFTC.
- (2) The powerful operation is for 20 minutes after setting.
- (3) Operation is continued forcibly thermo-ON for 20 minutes after the powerful operation is finished.
- (4) Pressing the "START/STOP" button and "POWERFUL"button during powerful operation will cancel the powerful operation.
- (5) If the sleep timer is set during powerful operation, the powerful operation will be canceled.
- (6) When the powerful operation is set, the fan speed will be set to "HIGH" and the compressor's maximum speed will be set to CMAX2 during powerful operation. The compressor's lower limit speed is CKYMIN_PW.
- (7) The fan speed increases by FNUPPW_C.
- (8) After the powerful operation is ended, the system automatically operates with the previous settings used before the powerful operation.


- 68 -

Dehumidifying 30sec. Room temperature judgement Room temperature ပ္ 5 °C Cooling preset temperaure -1.33°C -0.66°C Room temperature judgement Stop Start Start/Stop Switch Operation lamp Thermostat judgement Med 5 min. OFF/1 min. ON Indoor fan Lo/Silent 15 sec. 15 sec. Med Outdoor fan Lo Reversing valve 1 min.

Notes:


- (1) If the room temperature is (cooling preset temperature) (1.33°C) or less after 30 seconds from starting the operation, the operation is done assuming as the preset temperature = (room temperature at the time) (2°C).
- (2) The indoor fan is operated in the "Lo" or "Silent" mode. During thermo OFF, indoor fan will be OFF 5 minutes and ON for 1 minute
- (3) When the operation is started by the themostat turning ON, the start of the indoor fan is delayed 32 seconds after the start of compressor operation.
- (4) The compressor is operated forcedly for 3 minutes after operation is started.
- (5) The minimum ON time and OFF time of the compressor are 3 minutes.






Notes:

- (1) Pressing the "POWERFUL" button will reduce the temperature setting by PWSFTSD.
- (2) The powerful operation is for 20 minutes after setting.
- (3) Operation is continued forcibly thermo-ON for 20 minutes after the powerful operation is finished.
- (4) Pressing the "START/STOP" button and "POWERFUL" button during powerful operation wil cancel the powerful operation.
- (5) If the sleep timer is set during powerful operation, the powerful operation will be canceled.
- (6) If the differential(the room temperature the temperature setting) is "the differential ≥3 °C" after powerful setting, the compressor's maximum speed during powerful operation will be set to SDMAX. Then the differential reduce "the differential ≤2.33 °C" during powerful operation, the compressor's speed will be set to SDRPM.
 - If the differential (the room temperature the temperature setting) is "the differential < 3 $^{\circ}$ C" after powerful setting , the compressor's minimum speed during powerful operation will be set to SDRPM.
- (7) After the powerful operation is ended, the system automatically operates with the previous settings used before the powerful operation.







Notes:

- (1) During CLEAN operation period, heating mode will change to fan mode when HEX temparature is "CLNEVP" or more except force 3 minutes operation.
- (2) For multi connections, CLEAN operation is limited to fan mode.

MODEL: RAS-EH18RHLAE / RAC-EH18WHLAE


COOLING, DEHUMIDIFYING, DEFROSTING






MODEL: RAS-EH24RHLAE / RAC-EH24WHLAE

COOLING, DEHUMIDIFYING, DEFROSTING





AUTO SWING FUNCTION

	PRESENT CONDITION			ODERATING OREGISIOATION	DESERVACE	
INPUT SIGNAL	OPERATION OPERATION MODI		AIR DEFLECTOR OPERATING SPECIFICATION		REFERENCE	
KEY INPUT	STOP	EACH MODE	STOP	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.	
			DURING ONE SWING	STOP AT THE MOMENT.		
DURING OPERATION		COOL STOP		START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD		
			DURING SWINGING	STOP AT THE MOMENT.		
THERMO. ON (INTERNAL FAN ON)	DURING		TEMPORARY STOP	START SWING AGAIN.		
THERMO. ON (INTERNAL FAN OFF)	DURING DRY		DURING SWINGING	STOP SWINGING TEMPORARILY. (SWING MODE IS CLEARED IF SWING COMMAND IS TRANSMITTED DURING TEMPORARY STOP.)		
MAIN SWITCH ON	STOP	COOL DRY	STOP DURING ONE SWING	INITIALIZE ① DOWNWARD ② UPWARD		
	DURING OPERATION	EACH MODE	STOP DURING SWINGING	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD	INITIALIZE AT NEXT OPERATION.	
			DURING INITIALIZING	② UPWARD	OF LITATION.	
			STOP	INITIALIZING CONDITION OF EACH MODE.		
CHANGE OF OPERATION	COEDATION EACH MODE		DURING SWINGING	STOP SWINGING AND MODE BECOMES INITIALIZING CONDITION.		

1. Control power circuit




Fig.1-1

- An AC power supply from indoor unit passes through the 3.15 A fuse, varistor (VA001), and noise filter circuit and rectified
 and smoothed by DB1 and C003 to become a DC current 325 V. It is then supplied to indoor fan motor drive circuit, and
 switching power circuit.
- The switching power circuit, as controlled by IC001, drives the primary winding of the transformer (T001) to produce a specified voltage at the output winding. [The output terminal (pin ⑤) of IC001 has a switching voltage. But it changes in voltage peak and oscillation period depending on the power load. usually,the oscillation frequency when the air condition operation is about 64.5 kHz. In the standby state, the oscillation frequency is lowered to a level as low as 64.5 kHz or so to reduce the standby power.]
- The outputs of the output windings of the transformer is rectified and smoothed to become DC voltages at primary 18.5 V, 12 V, and 8.5 V respectively. The primary 18.5 V is supplied to the drive circuit of the indoor fan motor, the 12 V is supplied to each vane motor and to the drive circuits of the cleaning unit driving motor and other equipment, and the 8.5 V is adjusted to a stable 5 V by IC101 and supplied to the microcomputer peripheral circuit.

Check

If a failure in a part or circuit has produced an abnormal current in the power supply, the 3.15 A fuse will melt down to prevent further damage. If the 3.15 A fuse melts down, check the indoor fan motor, switching electrical circuit, and other components and replace any defective part.


Check


If an abnormally high voltage is applied to the power supply, the 3.15 A fuse and varistor (VA001) will prevent further damage. If a high voltage results in the 3.15 A fuse melted down, the varistor (VA001) should have deteriorated and destroyed. Therefore replace it at the same time.

Caution

The primary circuit of the transformer (T001) has a voltage to ground. Guard against electric shocks.

2. Reset Circuit





- Reset circuit is to initialize the indoor unit microcomputer when switching ON the power or after recovering from power failure.
- Low voltage at pin ③ resets the microcomputer and Hi activates the microcomputer.
- Waveform of each part when switching ON the power and when shutting down is shown in the Fig. 3-2.
- After switching ON the power, ① pin of IC501 supply voltage and ③ pin of microcomputer becomes Hi when DC5V line rises and reaches approximately 4.4V or higher.
 - Then, resetting will be cancelled and microcomputer starts operating.
- After shutting down the power, ① pin of IC501 supply voltage and ③ pin of microcomputer becomes Lo when DC5V line falls and reaches approximately 4.2V or lower.
 - Then, the microcomputer will be in reset condition.

3. Drive circuit of the indoor fan motor





Fig. 3-1

< The circuit check (For test) >

		The state of the s
Name	Test point	Test voltage
Motor drive power	CN2 ①pin- ④pin	About 325V
Motor contorl power	CN2 ⑤ pin- ④ pin	About 15V
Motor speed signal	CN2 6 pin- 4 pin	About 2-6V
Motor rotation speed debug	CN2 ⑦ pin- ④ pin	About 7.5V


- * The voltage above is all motor operation vol. when yon start the test, take care of your connector, do not touch the different pin together.
- * The voltage of pin 6 pin 4 , pin 7 4 maybe different from above.

< Pin 6 - Pin 4 voltage one example >



* The different mode maybe have different FAN rotation speed.

< Typical circuit waveform >



- The indoor fan motor receives VDC (motor drive power supply), VCC (power supply for the control circuit inside the motor), and VS (speed command voltage) from CN2. The indoor fan motor returns an FG signal of a frequency that matches the rotation speed.
- VCC stabilizes the primary 18.5 V power supply into 15 V by using Q201 and supplies it.
- * While on standby for a remote control signal, the Q201 shuts down the VCC and reduces the standby power.
- The VS receives a command voltage from the microcomputer . The VS terminal undergoes an analog voltage that matches the Lo level time ratio of the pulse signal from pin (69) of the microcomputer. (See Fig. 3-2.)
- The FG terminal undergoes a signal of 12 pulses per revolution of the motor shaft. By counting the pulse rate, the microcomputer recognizes the motor speed, thereby performing feedback control.

4. Buzzer Circuit





Fig.4-2 Buzzer Operation

5. Remote control reception circuit



[Typical communication waveform]





Fig. 5-2

· An infrared signal from the remote control unit is converted to an electrical signal by the remote control light-receiving unit and is received by the microcomputer. Data is transmitted as digital data 0 and 1 by changing the interval of the basic pulses at about 420 μ s.

6. Room temperature, heat exchanger thermistor circuits



- The thermistor is used for detecting the room temperature and indoor unit heat exchanger pipe temperature.
- The thermistor is a sensor that changes its resistance value according to the temperature of the element and the microcomputer recognizes the analog voltage provided by the resistance voltage division with the fixed resistor as temperature signals.
- The relationship between the temperature of the thermistor and the circuit voltage is roughly as shown in Fig. 6-1 and Fig. 6-2. When it is easy to measure between the terminals of CN4 in actual measurement, use the graph of Fig. 6-3




Fig. 7-1 Dip switch Circuit

Fig. 7-1 shows the dip switch circuit; the table shown in Fig. 7-2 are function and setting position from 1 −6 of the switch No.

SW No.	ITEM	F U	NCTION	
1 1	AUTO RESTART	OFF* ENABLE	ON DISABLE	
2	CARD KEY MODE	OFF* DISABLE	ON ENABLE	
3	CARD KEY LOGIC SELECT	OFF* INPUT HIGH ACTIVE	ON INPUT LOW ACTIVE	
4	HEATING/COOLING ONLY MODE SELECT	OFF* HEATING	OFF HEATING ONLY	ON COOLING ONLY
5	HEATING/COOLING ONLY MODE SELECT	OFF* COOLING	ON REALING ONLY	OFF COOLING ONL!
6	REMOCON ID SELECT	OFF* FACTORY	ON SELECT	

Fig. 7-2 Functions of Dip switch


DIP switch DSW1

NOTE:


^{*} Marking is position of shipping [FACTORY default setting]

8. Initial Setting Circuit (IC531)

- When power is supplied, the microcomputer reads the data in IC531 (E²PROM) and sets the preheating activation value and the rating and maximum speed of the compressor, etc. to their initial values.
- Data of self-diagnosis mode is stored in IC531; data will not be erased even when power is turned off.



9. Temporary Switch Circuit



- The temporary switch is used to operate the air conditioner temporarily when the wireless remote control is lost or faulty.
- The air conditioner operates in the automatic mode by pressing the temporary switch. If the power switch is set to OFF then ON it also operates in the automatic mode when the temporary switch is pressed.

10. Indoor/outdoor communication circuits






Fig. 10-1





- Indoor and outdoor communications are conducted by using lines 2 and 3 of F cable. Line 2 of F cable is shared with a transmission channel that powers the outdoor unit.
- Data communicated between the indoor and outdoor units are outputted from the microcomputer as serial signals and are transmitted as demodulated by a 30 kHz carrier wave. (Both the indoor and outdoor microcomputers directly output a signal demodulated at 30 kHz.)


Check

If a cable poorly inserted in the indoor terminal board or some other failure overheats the terminal board and the temperature fuse of the terminal board blows out, the power to the indoor communication circuit will be shut down to stop the communications function.

Check

If communication fails between the indoor and outdoor units for some reason, the product will give a self-diagnosis display either by "the timer lamp blinking 3 times" or "the timer lamp blinking 12 times" depending on the cause.

Indoor/Outdoor communication fault circuit judgement



- 1. Failure happen during unit running
 - 【If ①failure】Outdoor: LD301 blinking 9 times / Indoor: no failure display
 - [If ②failure] Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 3 times
 - [If @failure] Outdoor: LD301 blinking 9 times / Indoor: no failure display
 - If @ failure Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 3 times
- 2. Failure happen during standby mode but outdoor unit not yet enter hibernation mode
 - [If ①failure] Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 12 times
 - [If ②failure] Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 3 times
 - 【If ③failure】Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 12 times
 - [If 4] failure Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 3 times
- 3. Failure happen during standby mode but outdoor unit already enter hibernation mode
 - 【If ①failure】 Outdoor: no failure display / Indoor: the timer lamp blinking 12 times
 - 【If ②failure】Outdoor: no failure display / Indoor: the timer lamp blinking 3 times
 - [If ③failure] Outdoor: no failure display / Indoor: the timer lamp blinking 12 times
 - [If @failure] Outdoor: no failure display / Indoor: the timer lamp blinking 3 times

When outdoor unit is in hibernation mode, outdoor microcomputer is off,

so the outdoor unit can't display the failure.

11. Stepping motor drive circuit





Fig. 11-1

[Connector circuit waveform while the motor runs]
Voltage waveforms of different phases as viewed from
the OV line while the motor rotor is turning counterclockwise
as viewed from the shaft side



- Fig. 11-2
- Each stepping motor runs as excited in 1 or 2 phases at 100 PPS or 200 PPS.
- The excitation pattern passes the microcomputer (IC601) and then the driver IC and excites the coil of each stepping motor.
- Some models not need to install the horizontal sweep motor.

12. Run status and alarm signal output circuit





Fig.12-1

Fig. 12-1 is the control circuit of run status and signal output in main PWB. The pin ② of CN5 is used to show run status and the pin @ of CN5 is used to warn people when failure occurrence. If customer want to use this function, need to use the adapter(sold separately) to achieve it. the adapter is optional and the detail circuit refer to following circuit,



LED1 is on When air-condition is running and is off When air-condition is stopping. We can know the status of air-condition by LED1. LED2 is off When air-condition in normal condition and is on when air-condition in failure occurrence, we can repair it in time. The brightness of the lamp(LED1, LED2) can be determined by adjusting the resistance(R5,R6) value.

* The adapter must to be used because of noise interference. The noise will cause air-condition failure. the voltage from customer's home supply to adapter must be in the 5~24V, the current is less than 10mA. If the voltage is lower than 5V, optocouplers will not be action; once the voltage is higher than 24 V, optocouplers adapter will be damaged.

DESCRIPTION OF MAIN CIRCUIT OPERATION

MODEL: RAC-EH18WHLAE, RAC-EH24WHLAE

1. Power Circuit.




Fig. 1-1

*This circuit rectifies the AC voltage 230V applied between terminal L and N and creates a DC voltage.

The voltage become 320-360V when the compressor is operated.

- ※ Importance components.
- Inverter circuit for compressor (Q901 to Q906).
 The elements constitute the inverter part.
- (2) Diode stack (DB602). The diode stack rectify AC Voltage 230V applied between the Terminal board L and N to DC Voltage.
- (3) Smoothing capacitor (CO21 to CO22, 610uF, 450V).
- (4) IGBT for the power factor improvement (Q601).
- (5) Surge absorber, varistor 1 and 2. The surge absorber and varistor absorb exogenous surge, including inductive lightning.
- (6) Noise filter (COO1, COO2, COO6, COO7, CO13, CO14, NF Coil). The noise filter absord electrical noise generated when the compressor operates and when exogenous noise mixed through the power line. In order to protect electronic parts.

<Reference>

When the inverter circuits for compressor (Q901 to Q906) have a failure or improper connection, the compressor may stop immediately after its starts, due to "Abnormal low speed", "Switch failure", "IP Stop", etc.

<Reference>

When the diode stack (DB602) has failure, DC voltage can not be generated, completely disabling the operation of the compressor. Also note that 2A fuse may have blown.

<Reference>

The smoothing capacitor smoothes (average) voltage rectifier by the diode bridge.

<Reference>

 It will improve efficiency during compressor load become heavy when current flow thru the chopper period of Q601.


<Reference>

Be sure to ground the surge absorber and varistor. without grounding, the surge absorber and varistor do not operate normally.

<Reference>

Without grounding, the noise filter on the left do not operated normally.


2. Power Circuit (Low Voltage)



Fiq. 2-1

- The 230V VAC voltage is rectified to DC voltage (B-12V, 16V, 12V, 5V) pass through switching control IC (IC1), switching transformer.
 - (1) B-12 Power supply for electrical expansion valve.
 - (2) 16V Power supply for driver circuit of compressor and fan motor, IGBT action.
 - (3) 12V Power supply for 4-way valve relay, power relay, motor current amplification.
 - (4) 5V Power supply for microcomputer, peripheral circuit.

MODEL RAC-EH18WHLAE, RAC-EH24WHLAE



**Because high voltage flows, be careful about electric shock. Also, be careful about short-circuit accidents by improper connection of measuring instruments, which can damage the board.

3. Power Supply Circuit for Board

The voltage specification of the power supply circuit are as follow.

<Checking points>

Output Name	Voltage Specifications Value	Main Load	±Measurement Position	Example of failure mode for each output failure (Reference)
5V Output	5 ^{±0.4} V	Microcomputer Thermistor	Tester (+) terminal: J96 (5V indication) Tester (-) terminal: J138 (0V indication)	The troubleshooting lamp LD301 does not indicate and the outdoor unit does not operate.
12V Output	12 ^{±1} V	Microcomputer IC2,3 and 4 Relay Circuit	Tester (+) terminal: J139 (12V indication) Tester (-) terminal: J138 (0V indication)	The troubleshooting lamp LD301 does not indicate and the outdoor unit does not operate.
16V Output	15.5 ^{±1.5} V	Compressor Inverter Ciruit Fan Inverter Circuit	Tester (+) terminal: J111 (16V indication) Tester (-) terminal: J138 (0V indication)	The troubleshooting lamp LD301 blinks 3,4 or 12 times and the outdoor unit stops.
B-12V Output	12 ⁺³ V	Expansion Valve	Tester (+) terminal: J133 (B-12V indication) Tester (-) terminal: J130 (B-0V indication)	The troubleshooting lamp LD301 blinks 5 times and the outdoor unit stops.

^{*}When checking each voltage, if the voltage specifications above are met, the power supply circuit for the board is functioning normally.

4. Temperature Detection Circuit




Fig. 4-1

- OH thermistor circuit detect the temperature at the surface of compressor head, DEF thermistor circuit detect the defrosting operation temperature.
- A thermistor is a negative resistor element which has characteristics that the higher (lower) the temperature, the lower (higher) the resistance.
- When the compressor is heated, the resistance of the OH thermistor becomes low and \oplus 5V is divided by OH thermistor and R301 and the voltage at pin $\overline{(8)}$ of microcomputer.
- Compare the voltage at microcomputer pin (78) and setting value stored inside. If the value exceed the set value, microcomputer will judge that the compressor is overheated and stop the operation.
- The microcomputer read the outdoor temperature by Outside Air thermistor and transfer it to the indoor unit, thus controlling the compressor rotation speed according to the set value in the EEPROM of indoor unit and switching the operation mode (outdoor fan on/off etc.) to DRY mode.

Below table show the typical values of outdoor temperature in relation to the voltage.

Table 4-1						
Outside Air Temperature (°C)	-10	0	10	20	30	40
Voltage at both side of R303 (V)	1. 19	1. 69	2. 23	2. 75	3. 22	3. 62

<Reference>

When the thermistor is open condition or disconnect, microcomputer $pin 78 \cancel{79} \cancel{83}$ are approx. 0V; When thermistor is shorted, they are approx. 5V and LD301 will blink 7 times.

However, an error is detected when only the OH thermistor is shorted and will enter blinking mode after 12 minutes start the compressor operation.

5. Outdoor DC fan motor control circuit

• This model is built with DC fan motor control circuit inside outdoor electrical unit.




Fig 6-1

This DC fan motor is control by outdoor microcomputer that follow the operating instruction received from indoor microcomputer. The DC current that flow from R741 will presume actual operation speed and control the rotation to follow the operating instruction. Based on this DC current it will detect a over current and other fan motor failure.

(1) Fan motor speed controller during starting

Due to the interference of strong wind etc., operation movement is changed based on fan direction and rotation speed as shown below during starting of operation.

In addition, the fair wind is define as wind that blow to outside direction using Mouth Ring part.

At strong and contrary wind ... The rotational speed is not controlled as to protect the equipment

and fan will rotate reversely depend on the wind. Automatically

start when wind condition become weak.

At contrary wind The rotational speed is controlled in fair wind direction after it

slowly reduce the speed and finally stop.

At fair wind The rotational speed is controlled as it is.

At strong fair wind The rotational speed is not controlled as to protect the equipment

and fan will rotate reversely depend on the wind. Automatically

start when wind condition become weak.

(2) Fan motor speed controller during unit operating


There is a case where fan rpm is reducing during rotating caused by interference of strong wind If this condition continue in long period, fan will stop rotating. (LD301 : 11 times blinking) The unit will restart according to control as per during start (1).

- (3) Method of confirming self diagnosis LD301 lamp: 12 times blinking

 If the unit stop and LD301 on the pwb blinking 12 times [fan lock stop is detected], follow below steps to confirm it.
 - 1. Fan lock stop is detected when something has disturb the fan rotation by inserting material into propeller fan or ice has growing inside outdoor unit caused by snow.

 Remove it if found something is bloking the fan.
 - 2. Confirmed that CN24 connector is securely inserted. Fan lock stop is detected also when connector is not properly inserted. Please securely insert if found any disconnection.
 - 3. Fan lock stop also can be detected where strong wind blown surrounding the unit. Please confirm after restart the unit. (It may take few minutes to operate the compressor) It is not a malfunction of electrical unit or fan motor if the unit run continuesly after restart the unit.
 - 4. Check fan motor condition as below procedure.

[Checking Fan Motor] procedure



- 5. Reconnect again fan motor connector (CN24).
 - **Please confirm above checking procedure if found 2A fuse blown.

If fan motor is broken, replace both electrical unit and fan motor.

Caution

**Beware of electric shock due to high voltage when conducting an operation check.

Power supply for DC fan motor and compressor is common (DC260-360V).

6. Electric expansion valve circuit




Fig. 3*.

- The electric expansion valve is driven by DC12V. Power is supplied to 1 or 2 phases of 4-phase winding to switch magnetic pole of winding in order to control the opening degree.
- Relationship between power switching direction of phase and open/close direction is shown below. When power is supplied, voltages at pins 4 to 1 of CN15 are about 0.9V and 12V when no power is supplied. When power is reset, initial operation is performed for 10 or 20 seconds. During initial operation, measure all voltages at pin 4 to 1 of CN15 by using a multimeter. If there is any pin with voltage that has not changed from 0.9V or 12V, expansion valve or microcomputer is broken.
- Fig. 6-2 shows logic waveform when expansion valve is operating.

Table 3*.									
CN15	w		Drive status						
pin no.	Wire	1	2	3	4	5	6	7	8
1	WHT	ON	ON	0FF	0FF	0FF	0FF	0FF	ON
2	YEL	0FF	ON	ON	ON	0FF	0FF	0FF	0FF
3	ORG	0FF	0FF	0FF	ON	ON	ON	0FF	0FF
4	BLU	0FF	OFF OFF OFF OFF ON ON ON						
Operation mode $1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5 \rightarrow 6 \rightarrow 7 \rightarrow 8 \text{VALVE CLOSE} \\ 8 \rightarrow 7 \rightarrow 6 \rightarrow 5 \rightarrow 4 \rightarrow 3 \rightarrow 2 \rightarrow 1 \text{VALVE OPEN}$									




Fig. 3*/

With expansion valve control, opening degree is adjusted to stabilize target temperature by detecting compressor head temperature. The period of control is about once per 20 seconds and output a few pulse.


7. Reversing valve control circuit.


This model reversing valve control used to control the relay 0N/0FF of the reversing valve, and also control the coil of the reversing valve 0N/0FF.

The relay ON/OFF has different type when in the different operation mode.

You can see each operation mode as follows. If the reversing valve not connected or all the condition not the same as follow, it may be something wrong with the reversing valve circuit.

Operation	Point Mode	Micon 9 pin-0V	HIC 35 pin-0V	CN2(1)- CN2(4)	
Cooling Normal Cooling		Hi	OV	AC230V	
Heating	Normal Heating	Lo	12V	OV	
noutring	Defrost	Hi	OV	AC230V	





SERVICE CALL Q & A

There is a difference between the set

temperature and room temperature.

COOLING MODE The compressor has stopped Check if indoor heat If the air conditioner operates in suddenly during cooling exchanger is frosted. cooling mode when it is cold, Wait for 3-4 minutes until it is the evaporator may get frosted. operation. defrosted. **DEHUMIDIFYING MODE** Q1 Sound of running water is heard from Normal sound when refrigerant flows in pipe. indoor unit during dehumidifying. Q2 Cold air comes out during a To improve the dehumidification efficiency performs dehumidifying operation. quiet fan operation. Therefore the air is cold and it is not a malfunction. The operation does not stop even by It sets to perform dehumidifying operation by setting setting the temperature higher than the temperature slightly lower than remote controller room temperature on the remote setting. controller. AT STARTING OPERATION Q1 When only the circuit breaker is turned To ensure correct opening and closing of the deflector, ON, the deflector at the air outlet move they will move when power is turned on or the unit is to be operated in order to check its fully opened and even if the cooling button is not closed positions. pressed. **OTHERS** When operation is started, the compressor rotation Loud noise from the outdoor unit is speed goes to maximum to increase the cooling heard when operation is started. capability, so noise becomes slightly louder. This does not indicate a fault. The compressor rotation speed changes according to Noise from the outdoor unit the difference between the thermostat set temperature occasionally changes. and room temperature. This does not indicate a fault.

for the space.

There may be a difference between the set temperature


and room temperature because of construction of room, air current etc. Set the temperature at a confortable level

Disassembly and assembly procedure.

MODEL: RAS-EH18RHLAE


1. Front panel

- Be sure to hold the lower left and right sides of the front panel with both hands and pull it towards you to open it until it is completely open.
- 2) Push the axis of the right arm outward to release the axis.
- 3) Move the front panel to the left to release the axis of the left arm.




2. Frontcover

- 1) Remove the terminal cover fixing screw and hold the knob to remove the terminal cover.
- 2) Remove the 2 frontcover fixing screws.
- 3) Open the horizontal wind deflector a little, and open the frontcover to a position where it can be removed.
- 4) Release the snap-fit lock (inside the frontcover) by pulling the center portion of the frontcover.




5) Release the claws on the top (3 places) and pull the lower side of the frontcover towards you to remove it.




Caution at the time of assembly

- 1) Open the horizontal wind deflector a little, and fit the claws (2 places) inside the frontcover securely.
- 2) Insert the snap-fit lock (inside the frontcover) securely by pushing the frontcover center side of where the snap-fit lock is located.
- 3) Firmly fit the claws (3 places) on the top portion of the frontcover.




3. Indoor Electrical


1) Open the electrical side elec-cover to the right and remove it.



- 2) Remove the heat exchanger earth wire fixing screw.
- 3) Remove the P lock and each lead wire connector.




- 4) Remove a screw on the front left of the electrical.
- 5) Lift the lower part of the electrical product and remove the hooks at the top of the cabinet.



Caution at the time of assembly.

1) Fix the electrical parts and bundle each lead wire with P lock.




2) Path of lead wires as shown in the table below.
* The motor for CN9 left / right air direction deflector is not compatible with this series.


Lead wire	Lead wire through hole "A"					
CN4	Room heat exchange thermistor					
Lead wire through hole "B"						
CN2	Indoor fan motor					
CN9	Motor for left and right wind direction					
CN12 Motor for up and down wind direction						
CN16A	Indication board					
CN17	Humidity sensor					

4. Light receiving and indication board assembly

1) Remove the fixed claws (2 places) on the light receiving / indication board and remove it, slide the LED cover to the left and release the hooks (2 places) on the back side to remove it.




2) Remove the LED cover mating claw, open the LED cover, and remove the board.




5. Fan motor and tangential fan


1) Loosen the fan motor fixing screw.




2) Press the fixing claws (2 places) on the right side of the fan motor holder and open it to the right to remove it.




3) Pull out the fan motor to the right.



- 4) Remove the fixing screw on the left side of the evaporator.
- 5) Open the fixed claw on the lower side of the evaporator slightly to the left, remove it from the fixed claw and shift up the evaporator.




6) While shifting up the evaporator, pull out the bearing and tangential fan to the left to remove.




Cautions when assembling fan motor and tangential fan

1) For tangential fan installation, mark the top of the dew plate and tighten the screws according to the first plate of the flow fan




6. Motor for flap (up and down wind direction deflector)

1) Press the fixing claw on the upper side of the cable guide with a screwdriver then open it to the right, and push the cable guide backward to remove it.



2) Remove the motor fixing screw and remove it from the hook.



Procedure for Disassemble and Reassemble

MODEL: RAS-EH24RHLAE

1. Front Panel

 Pull the panel by holding it both lower sides with both hands.




Fig. 1

(2) When the panel opens full, pull the inner part of the right arm inward and pull the panel forward while closing it gradually.






Fig. 2

2. Front Cover



(1) Remove the caps and uncrew at lower portion of the front cover.




(2) Firmly press 4 hooks at top of front cover by tools until the hook release from slot.

(3) Pull the front cover to front side.


3. Main P.W.B and Reception/Indication P.W.B

- (1) Remove each connector from the lead wire.
- (2) Remove the two P.W.B supports from the main P.W.B.
- (3) After removing the reception/indication P.W.B cover, pull the support hook at the right side of the reception/indication P.W.B and pull out the P.W.B forward.




4. Tangential air flow fan

(1) Press to unhook (2 places) between drain pan and cabinet and pull the claw forward to remove the drain pan.



(2) Unscrew 2 portions at evaporator support and tangential fan.



(3) Remove the locking hook of the bearing cover from the cabinet. Gently pull up the evaporator with bearing cover by holding it at lower side and pull out tangential fan.




Fig. 8

- (4) Remove the two lock screws from the fan motor holder and one screw from the evaporator support plate.
- (5) Pull up the evaporator by holding it at the lower side. Insert a screwdriver through the space between the evaporator and fan motor holder and loosen the fan lock screws to remove the air fow fan and fan motor.





Fig. 8


STRUCTURE OF AN INDOOR UNIT ELECTRIC PARTS



Removing electrical parts

- 1. Remove the electrical parts cover.
- 2. Remove the connectors from the CN4 (heat exchange thermistor),
- CN9 (Vertical sweep motor) and CN2 (fan motor), **CN12** (horizontal sweep motor).

 3. Remove four lock screws.



Removing control P.W.B.

- . Pull off all the wires from terminal 1,2,3 or remove the terminal [1,2,3] from the chassis.
- 2. Remove the P.W.B from the P.W.B support.

Remove the indicating P.W.B.

- 1. Remove the connector from the CN16A on the control P.W.B.
- 2 Remove the upper hook from the indicating P.W.B. lock resin, pull the P.W.B. forward a little and remove it.


Procedure for Disassembly and Reassembly

OUTDOOR UNIT

MODEL RAC-EH18WHLAE, RAC-EH24WHLAE

1. Electrical Parts

- (1) Remove the top cover fixing screws and lift the cover to remove it.
- (2) Remove the handle cover fixing screws and push it down to take it out.



(3) Remove the electrical box fixing screws.





Fig. 10

2. Dismantle procedure of MAIN PWB.

(1) Remove terminal cover.



(2) Remove the terminal block screw, inductance line, line clip, GRN wire, LN123 wire.




Fig. 11

(3) Set the electrical box upside down.




Fig. 12

(4) Remove each connector and earth cable from the lead wire. Then, remove the electrical box.




Fig. 13

3. The PWB.

(1) Remove the electrical cover.




Fig. 14

(2) Remove the PWB from the support.






Fig. 15

Inspection instructions





Troubleshooting support

Nº	Function	Description
1	Self-diagnosis display [Display on the indoor unit side]	 The failure mode detected on the indoor unit side is displayed by blinking the "timer lamp". And a failure detected on the outdoor unit side will be indicated by the "timer lamp" blinking 4 times. If the outdoor unit side detects a failure, the product will first conduct several operation retrials. There are some failure modes with no lamp display while retrials are continued. [Failure mode where retrials are continued and the indoor unit lamp does not end up giving a display] OH thermistor heat-up Overload lower limit cut Low-frequency things
	[Display on the outdoor unit side]	The failure mode detected on the outdoor unit side is displayed by blinking the "LD301". Detecting a failure will stop the outdoor unit and keep blinking the LD301 until it is restarted. (The communication error will persist until the communication is reestablished.)
2	Self-diagnosis memory	 The failure modes detected on the indoor and outdoor unit sides are stored in the nonvolatile memory of the indoor unit and can be read later on. (The memory will remain even after power-off.) The failure modes detected on the outdoor unit side are written in memory every time any such mode occurs. The failure mode can therefore be detected on the indoor unit side without waiting for the retry frequency to reach the display of the indoor unit lamp. Moreover, the normal self-diagnosis display function which rarely occurs will store and display failure modes that do not end up displaying the indoor unit lamp. (Any such mode may be unable to be stored if indoor or outdoor communications is in a failure.) The product stores 5 last-stored failure modes. There is a function for deleting memory. Once you clear the memory and run the product for several days, you can read the failure modes and check them, thereby detecting the less frequent failure phenomena. Failure modes can be checked by both the blinking of the lamp of the indoor unit and the display of the remote control liquid crystal display.

^{*}The "self-diagnosis function of the communication circuit" available in our conventional models is now incorporated as part of the normal self-diagnosis function. In the case of a failure in the communication circuit, you do not have to conduct a special operation and the operations can be automatically divided into 3 blinking operations and 12 blinking operations of the timer lamp.

DISCHARGE, PROCEDURE AND POWER SHUT OFF METHOD FOR POWER CIRCUIT



WARNING




Caution

- Voltage of about 325V is charged between the terminal of smoothing capacitor.
- During continuity check for each circuit part of the outdoor unit, be sure to discharge the smoothing capacitors.

Discharge Procedure

- 1. Turn of the power.
- 2. After power turned OFF, wait for 10 minutes or more. Then, remove electrical parts cover and apply soldering iron of 30 to 75W for 15 seconds or more to (+) Positive (-) Negative terminals on the Main PWB as shown in the figure below, in order to discharge voltage in smoothing capacitor.




Other instructions

(1) Detaching and reattaching the receptacles for tab terminal

All the receptacles for connecting tab terminals are with a locking mechanism. Forcibly pulling any such receptacle without unlocking it will destroy it. Be on guard.


When reconnecting it, insert it securely all the way home.

· Receptacle types and how to unlock them



Vertical (with a resin case)

Hold the resin case and pull it out.




Horizontal (with a mild resin cover)

Hold the cancel button down on the mild resin cover while pulling it out.

(2) Detaching and reattaching the board connector

The product comes equipped with many board connectors provided with lock mechanism. Forcibly pulling any such part without unlocking it will destroy it. Be on guard. When reconnecting it, insert it securely all the way home.

Pinch the locking mechanism with your fingers and pull it out unlocked.




(3) Do not detach or reattach the connectors while energized

Do not under any circumstances detach or reattach the connectors while energized. That would destroy the board components and fan motor. For both the indoor and outdoor boards, ensure that the smoothing capacitor has discharged its electricity fully before you do your work.

SELF-DIAGNOSIS DISPLAY MODE (INDOOR SIDE)

While the "timer lamp" (orange), of the indoor unit is blinking, troubleshoot the product while referring to the table below.

- 1. How to count the lamp blinking frequency
 - •The product will repeat blinking with 2-second intermissions.
 - The blinking speed is as follows: on for 0.35 seconds and off for 0.35 seconds.



2. If you wish to try another operation while the lamp is blinking, operate the START/STOP button on the remote control unit twice. The first push will reset the indoor microcomputer, while the second will activate the product

Refer to the table below if the timer indicator (orange) is blinking.

LAMP BLINKING MODE	MAIN DEFECTIVE
2 SEC — — — ON	CE REFRIGERANT CYCLE DEFECTIVE
2 SEC	FORCED OPERATION OF OUTDOOR UNIT
2 SEC 3 TIM	INDOOR INTERFACE CIRCUIT
2 SEC4	OUTDOOR ELECTRICAL ASSEMBLY DEFECT
2 SEC9	ROOM OR HEAT EXCHANGER THERMISTOR OR HUMIDITY SENSOR DEFECT
2 SEC10	OVERCURRENT IN DC FAN MOTOR
2 SEC12	OUTDOOR INTERFACE CIRCUIT
2 SEC13	IC531 OR EEPROM DATA DEFECT
(LIGHT FOR 0.35 SE	C AT INTERVAL OF 0.35 SEC)


REFER TO THE BELOW TABLE IF THE INDOOR UNIT DOSE NOT WORK AT ALL.

FIX CN2 CONNECTOR	ACTION /REPLACEMENT PARTS, etc
FU1 (3.15A) FUSE BLOWN	REPLACE THE PART WHICH CAUSED BLOWING/DISCONNECTION OF FU1(3.15A) FUSE
COME OFF OR DISCONNECTION OF THE CONNECTOR FOR INDICATING P.W.B	FIX CN16 CONNECTOR
FAILURE OF CONTROL P.W.B	REFER TO THE SERVICE GUIDE FOR HOW TO DETERMINE THE FAILED PART

^{*} IF THE INTERFACE CIRCUIT IS DEFECTIVE WHEN THE POWER IS TURNED ON. THE SELF-DIAGNOSIS INDICATION WILL NOT WORK.

^{*} IF THE INDOOR UNIT CAN NOT BE OPERATED AT ALL.

MODEL RAC-EH18WHLAE. RAC-EH24WHLAE



-		LED INDICATION DURING STOP
LD301	SELF-DIAGNOSE CONTENT	CHECKING POINT AND REPAIR METHOD
OFF	NO POWER	NO POWER SUPPLY AT TERMINAL "L − N" → CHECK POWER CABLE CONNECTING CABLE MISCONNECTION → CHECK CONNECTING CABLE REACTOR CONNECTOR HALF INSERTION → CHECK REACTOR CONNECTOR F4 (2A FUSE) BLOWN → REPLACE FUSE AND CHECK OUTDOOR FAN MOTOR
	NORMAL STOP	NOT MALFUNCTION
1 TIME BL I NK	RESET STOP	FAN OPERATION≫1, WAITING COMPRESSOR TO START → NORMAL OTHER → IF STILL NOT SOLVE AFTER CHECK THE CONNECTION CABLE, CHANGE ODU CONTROLLER
2 TIMES BL I NK	PEAK CURRENT CUT	SERVICE VALVE NOT OPEN → CHECK SERVICE VALVE COMPRESSOR CONNECTOR NOT CONNECTED → CHECK CONNECTOR
3 TIMES BL I NK	ABNORMAL LOW SPEED ROTATION	OUTDOOR UNIT SURROUNDING IS BLOCKED $ ightarrow$ REMOVE THE CAUSE OF BLOCKING.
4 TIMES BLINK	SWITCHING FAILURE	THE CYCLE PIPE ABNORMAL → CHECK THE CYCLE PIPE CODIC (3×4) CONTROLER IS ARNORMAL OR COMPRESSOR IS ARNORMAL >
5 TIMES BL I NK	OVERLOAD LOWER	(ODU (%4) CONTROLLER IS ABNORMAL OR COMPRESSOR IS ABNORMAL) REFER TO THE SERVICE MANUAL [SELF-CHECK]
6 TIMES BL I NK	COMPRESSOR TEMPERATURE RISE	SERVICE VALVE NOT OPEN, REFRIGERANT LEAK → CHECK SERVICE VALVE, RE-CHARGE THE REFRIGERANT BAD CONNECTOR INSERTION, CIRCUIT DEFECT → CHECK THE CONNECTOR, CHANGE ODU CONTROLLER
7 TIMES BL I NK	THERMISTOR ABNORMAL	THERMISTOR CONNECTOR HALF INSERT $ ightarrow$ INSERT CONNECTOR SECURELY THERMISTOR WIRE SHORTED OR CUT, CIRCUIT DEFECT $ ightarrow$ CHANGE THERMISTOR, CHANGE ODU CONTROLLER
9 TIMES BLINK	COMMUNICATION ERROR	CABLE MISS CONNECTION, DISCONNECTIN → CHECK THE F CABLE COMMUNICATION CIRCUIT ABNORMAL → CHANGE ODU CONTROLLER
10 TIMES BLINK	POWER SUPPLY VOLTAGE ERROR	AC VOLTAGE ABNORMAL (BEYOND RATED VOLTAGE $\pm 10\% \to \text{SUPPLY CORRECT VOLTAGE}$ AC VOLTAGE NORMAL (WITHIN RATED VOLTAGE $\pm 10\% \to \text{CHANGE ODU CONTROLLER}$
11 TIMES BL I NK	FAN STOP BY STRONG WIND	TEMPORARY STOP DUE TO STRONG WIND → FAN WILL RE-START AFTER WIND BECOME WEAK
12 TIMES BL I NK	FAN LOCK STOP	TEMPORARY STOP DUE TO STRONG WIND. → FAN WILL RE-START MOVING LATER SOMETHING BLOCKED SURROUND OUTDOOR UNIT → REMOVE THE OBSTRUCTION CONDUCT OUTDOOR FAN MOTOR CHECK → REPLACE THE DEFECT PART
13 TIMES BL I NK	EEPROM READING ERROR	CHANGE ODU CONTROLLER
14 TIMES BLINK	DC VOLTAGE ABNORMAL	CONFIRM AC POWER SUPPLY & DC VOLTAGE IS NORMAL → CHANGE ODU CONTROLLER COMPRESSOR LOAD ABNORMAL → INSPECT THE COMPRESSOR
15 TIMES BL I nk	CIRCUIT ABNORMAL	CHANGE ODU CONTROLLER (SOME MODELS HAVE NOT 15 TIMES BLINK)
16 TIMES BL I NK	HIGH LOAD DURING STOP	SERVICE VALVE NOT OPEN → CHECK SERVICE VALVE SOMETHING BLOCKED SURROUND OUTDOOR UNIT → REMOVE THE CAUSE OF BLOCKING DUST ON INDOOR UNIT FILTER → CLEAN UP THE FILTER
		0

[OUTDOOR FAN MOTOR CHECK] DIAGNOSIS METHOD	OTHERS CHECKING POINT
1. SWITCH OFF MAIN POWER SUPPLY.	1. [REVERSING VALVE NOT OPERATE ERROR]
2. UN-INSERT OUTDOOR FAN MOTOR CONNECTOR CN24.	→UN-INSERT THE CONNECTOR AND CHECK
3. MAKE SURE NO ABNORMALITIES AT THE FAN SHAFT.	CHECK THE LEAD WIRE.
4. MEASURE RESISTANCE AT FAN MOTOR CONNECTOR CONTACT.	→IF OK CHECK F3(2A) FUSE, IF BROKEN
NORMAL RESISTANCE BETWEEN EACH TERMINAL	REPLACE THE FUSE OR ODU CONTROLLER.
REFER TO THE SERVICE MANUAL.	2. [COMMUNICATION ERROR] OR
5. IF NO ABNORMAL AND FAN MOTOR NORMAL,	OUTDOOR UNIT NO OPERATION
CHANGE ODU CONTROLLER.	→CHECK CONNECTING CABLE BETWEEN
	INDOOR UNIT AND OUTDOOR UNIT.

%3 F1 CURRENT VALUE BE DIFFERENT FOR DIFFERENT MODELS.


%4 ODU = OUTDOOR UNIT.

DD0010399B

CHECKING THE REFRIGERATING CYCLE

(JUDGING BETWEEN GAS LEAKAGE AND COMPRESSOR DEFECTIVE)

1. Troubleshooting procedure (No operation, No cooling)



Self Diagnosis Memory Function

Failure mode are stored in the non-volatile memory of indoor unit and can be redisplay by operating the remote controller. This function is very useful in checking the failure modes when either unintentionally switching OFF power supply or restarting the unit operation without conforming the number of blinking of self diagnosis lamp. Remote controller can be redisplay up to last 5 failure modes from the memory. However, failure modes which are rarely occur are also stored in the memory which caused the number of failure easily become more than 5. Thus, for some failure modes which are unable to retrieve because of the remote controller limit to redisplay only 5 failure modes, it can be found by clearing up the memory first then recheck the memory content again during the visit at the customer place.

<How to redisplay failure diagnosis>

- 1. Turn OFF the circuit breaker on the unit side. (wait for around 5 scond)
- 2. Press the [Mode (MODE)] button and select [Cool mode (🌣)]. The remote should be in 'Standby' mode.
- 3. Turn the circuit breaker ON.
- 4. Set the room temperature on the remote controller to 32°C by pressing the $\left[\begin{array}{c} I_{\text{temp}} \end{array}\right]$ (Temp Up)] button.
- 5. Set which failure information that need to be redisplay by using [Fan Speed)] button. (Refer to the corresponding table below)

Fan S	peed	Failure data stored
Auto	æ	Latest
Hi		2nd latest
Med		3rd latest
Lo		4th latest
Silent	4	Oldest

- 7. The indoor unit beep [Pi-] to indicate that it has just received the signal to redisplay the failure mode.
- Start counting the number of blinking of the Timer lamp (indicating indoor error) and Operation lamp (indicating outdoor error) and confirm it with indoor unit or outdoor unit self-diagnosis table.
- 9. After everything is completed, turn OFF the circuit breaker (must do without fail).

<How to clear the stored data>

- 1. Conduct the redisplay of failure mode. (Follow above procedure)
- 2. Turn the circuit breaker OFF. (Wait for 5sec or more)
- 3. Press the [Mode (MODE)] button and select [Dry mode (△)]. The remote should be in 'Standby' mode.
- 4. Turn the circuit breaker ON.
- 5. Set the room temperature on the remote controller to 16°C by pressing the [(Temp Down)] button.
- 6. While directing the remote controller towards the receiver of the indoor unit, press [Temp Down)] button and [On/Off)] button simultaneously.

(The remote controller perform signal transmission with the indoor unit.)

- 7. The indoor unit beep for a few second [Pi-] to indicate that it has just receive the signal. The data has been cleared.
- 8. After everything is completed, turn OFF the circuit breaker (must do without fail).

Notes:

- * This function is valid only once right after the power supply is turned ON and it will not work if other remote controller operation was made prior to it.
 - Also, this function will not work if above steps were not followed accordingly. (If the above procedures are not working, please repeat from the start.)
- * If nothing was stored in the memory, the lamp does not blink even the redisplay operation is carried out.
- * To carry out normal operation, turn OFF the power supply. After redisplay operation, the remote controller reception will not work as normal.


HOW TO CHANGE THE SHIFT VALUE SETTING TEMPERATURE

- 1. While pressing and holding ① (ON/OFF) button and ② button, press RESET [RESE] button on the same.

 Release RESET [RESE] button only and make sure that all marks on the remote controller display are indicated then release the ① (ON/OFF) button and ③ button. Remote controller now enters "Shift Value Change Mode".

 2. Press the ② (MODE) selector button so that the display indicates ⑤ (FAN) mode.

 3. Press the ① (ON/OFF) button and FANoperation will be started.
 - 4. Set the FAN SPEED with the (FAN SPEED) button according to the following FAN speed setting in order to choose the desired operation mode that is required for shift value setting temperature modification.
 - To change the shift value for COOLING mode operation, select either (HIGH) or (MED) FAN SPEED
 - To change the shift value for HEATNG mode operation, select either (LOW) or (SLENT) FANSPEED
 - 5. Press the (TEMP \checkmark or $^{\land}$) button to change the shift value. (The shift value changed with device producing beep sound.)




- 1. The displayed shift value, (HEAT) and (COOL) symbol on the remote controller display will disappear after 10 seconds.
- 2. The changed shift value will remain unchanged after turned o° the power.
- 3. If "O" is displayed on the remote controller display, it indicates the shift value is now at the initial setting.

SETTING THE PREVENTION OF MUTUAL INTERFERENCE FOR REMOTE CONTROLLER


a.) Other indoor circuit breakers should be disconnected.



- b.) Remove the back cover of the remote control.
- c.) Out the jumper as shown below.
- d.) Press "Reset" button after installing the battery.
- e.) Corresponding to the room electrical box dial code 6 to dial on.



Out (Attention: Remove the battery before cutting. Do not cut with electricity).



f.) Please use the remote cotrol to check the available models of corresponding indoor machines.

HOW TO CHANGE THE FAN SPEED IN COOLING MODE DURING THERMO OFF

Thefan speedin Cooling Mode during thermo off canbe changed by the remote controller. (Thisprocedure shall be implemented strictly by servicepersonnel only.) It is possible to return it to the default setting.

PROCEDRE

Press [POWERFUL] button and controller is OFF. [ECO] button simultaneously for about 5 seconds when the remote

Transmission sign lights up with beep from indoor unit simultaneously.

Mode Temp Fan Speed Speed Speed Lea e Home Improve the late of the

Beep sound pattern:

1) Default setting: Short beep 2) Changed setting: Double beep

	Fan speed during thermo o~	
Default Setting	Ultra low	
Changed Setting	Set fan speed (When auto fan speed	is set, the fan speed is low)

NOTE:

- (1) The selected fan speed will remain unchanged after the unit is turned o ...
- (2) If Timer reservation has been set, it will be canceled.

O Reset

(3) During time setting and timer setting, this operation cannot be set.

HOW TO CHANGE THE INTERMITTENT FAN HEATING SETTING

The intermittent fan control during thermo o in Heating mode can be changed by the remote controller.

(The procedure should be done only by service personnel.)

It is possible to select from 3 patterns.


PROCEDURE


Press (POWERFUL) button, (FAN SPEB) button and press RESET [RESE] button simultaneously.

Release RESET | [RESET] button only and make sure that all marks on the remote controller display are indicated, then release

(POWERFUL) button and (FAN SPEB) button.


Remote controller now enters "Intermittent Fan Control Change Mode".






Default: Pattern 1

Press [ROOM TEMPERATURE setting] [\sim (UP) / \sim (DOWN)] button. (The intermittent pattern changed with indoor unit beep sound)



Transmission sign lights with beep from indoor unit simultaneously.



	Pattern 1	Pattern 2	Pattern 3
Single model	Continuous	30sec ON / 210sec OFF repeatedly	50sec ON / 190sec OFF repeatedly
Multi	30sec ON / 210sec OFF repeatedly	50sec ON / 190sec OFF repeatedly	Continuous

NOTE:


- $(1) \quad \text{The indication of the selected intermittent pattern will disappear after 10 seconds.}$
- (2) The selected intermittent pattern will remain unchanged after the unit is truned o~.

DISPLAY OPERATION MODE SETTING


For operating indoor unit independently (without outdoor unit connection), remote controller must be set according to below procedures before send the signal to the indoor unit. New communication format between indoor and outdoor is required to communicate with outdoor unit.

PROCEDURE

1. While pressing and holding (ON/OFF)button and (UP/DOWN) button, press RESET (RESET)button on the same time. Release RESET (RESET)button only and make sure that all marks on the LCD display are indicated, then release the (ON/OFF)button and (UP/DOWN) button. Remote controller now enters "DISPIAY OPERATION MODE"for the indoor unit to run independently. Please ensure that when pressir (FAN SPEED) button, "" will be blinking.




- 2. Pressthe Mode (MODE) selector button to choose the desired operation mode.
- 3. Press (ON/OFF) button.
 Then , the indoor unit will starts to operate independently according the selected operation mode.



NOTE:

- (1) During "DISPLAY OPERATION MODE", " blinks on LCD of remote controller.
- (2) When operation stops, "DISPLAY OPERATION MODE" is canceled.

Diagnosis and troubleshooting of indoor electric parts, outdoor electric parts and refrigerating cycle



Checking the indoor unit electrical parts

Introduction

First check the failure phenomenon and status, and then move on to elaborate diagnosis.

Initiating troubleshooting

Turn off the power, wait at least 5 seconds, turn it back on, and observe the way the horizontal vanes move for about 30 seconds.

Check 1: Have the horizontal vanes moved? (Yes/No)



Set the remote control unit to cooling mode, temperature setting 16 $^{\circ}$ C and operate the product.

Check 2: Has the product received the remote control signal and has the "operation lamp" gone on? (Yes/No)

If you responded "Yes" to Check 2:

Check 3: Is the compressor of the outdoor unit running? (Yes/No)

If you responded "No" to Check 2:

Check 4: Does the "Temporary operation switch" work? (Yes/No)

Check results and next check items

Check 1	Check 2	Check 3	Check 4	Next check item
No	No	_	No	Go to "The power does not turn on".
Yes	No	_	Yes	Go to "The unit does not receive signals from the remote controller".
Yes	Yes	No	_	Go to outdoor side to check failure. Please refer diagnosis table for further checking if outdoor show fault.

1. Failure phenomenon: The power will not become turned on.

[Situation] Neither initialization, remote control, nor any other step works on the vane position at power-on.

[Estimated failure locations]

- · 3.15 A fuse blown out
- Estimated cause of fuse blowout · Abnormally high voltage applied to the power supply
 - Indoor fan motor out of order

· Control power circuit

Connector loose, wire break


- ontrol power circuit
- Power circuit out of order

[Cautions]

- · Before work, check the power supply voltage. An abnormal voltage may be being supplied in some rare occasions due to a defect in the indoor wiring (a wire break in the neutral wire of the single-phase 3-wire power supply).
- · If the 3.15 A fuse has blown out, eliminate the cause of the fuse blowout. Otherwise, there will occur another fuse blowout.
- If the 3.15 A fuse has blown out due to an abnormally high voltage to the power supply, the varistor (VA001) will deteriorate and become destroyed as well.
- · On a repair service visit due to the failure phenomenon of "The power will not become turned on", take a "3.15 A fuse" and a "varistor" with you.

[Diagnosis flow]

Initiating troubleshooting



2. Failure phenomenon: The product will not receive a remote control signal.

[Situation] The product does not receive a remote control signal. It is not very responsive.

(The product does run normally in response to the emergency operation switch.)

[Estimated failure locations] • Remote control failure, remote control low battery level, remote control poorly set

• Remote control light-receiving unit


• Connector loose, wire break

• Normal product (external factors: the remote control units for lighting equipment and other equipment, electrical noise, etc.)

[Cautions]

- Even if the product is trouble-free, a factor coming from outside the product may hamper the reception of signals from the remote control unit.
- · Batteries may decline in capacity at low temperatures. Old batteries decline particularly much in voltage in the morning and evening of winter, resulting in the poor arrival of remote control signals. Instruct your users to use new <u>alkaline batteries</u>.

[Diagnosis flow]



[Cautions in replacing the indicating P.W.B.] Be sure to replace the indicating P.W.B. components.

How to identify sources of jamming in the reception of remote control signals

The product may become poorly responsive to remote control signals due to external factors even though the [Situation] product itself is trouble-free.

[Estimating sources of jamming] Identify the installation status of the air-conditioner and the indoor and outdoor environments to identify possible causes of the jamming.

- · Indoor lighting equipment (quantity, type, location)
- · Remote control units of other electrical products and equipment
- · Is the grounding for the air-conditioner shared with other equipment?
- · Are the surroundings of the air-conditioner clear of wireless antenna?
- · Is the remote control light-receiving unit protected from direct sunlight?

Checking and actions]

Effects of lighting equipment (fluorescent lamps)

Checking points


- Turn on and off the lighting equipment and check for its effects on the reception of remote control signals.
- · When cold, the fluorescent lamp tends to emit infrared rays with wavelengths close to those used in remote control.

If you cannot detect the phenomenon about which your user is complaining at the time of your visit, such as "the product sometimes fails to receive remote control signals" and "the product fails to receive remote control signals in the morning alone", then turn off the lighting for about 20-30 minutes and wait for the fluorescent lamps to cool down before conducting another check.

There are even cases where the product fails to receive remote control signals for 1 to 2 minutes only after the lighting equipment is turned on.

- The noise status may vary with the dimming of the lighting equipment. In the case of lighting equipment with a dimmer, therefore, conduct a check with all the light intensities.
- · If the lighting equipment is the source of the jamming, the remote control light-receiving unit output usually shows a noise waveform as shown in the right-hand figure. In the case of slight jamming, this kind of waveform will not cause practical problems. However, intense degrees of jamming will disable the reception of remote control signals.
- When the fluorescent lamp is old and is flickering, it may cause disorders in the reception of remote control signals.


Output waveform of the remote control light-receiving unit



Actions proposed

- 1. Make it hard for light of the lighting equipment to enter the remote control light-receiving unit.
- Separate the lighting equipment from the indoor unit.
- · Raise the lighting equipment.
- Cover the upper half of the light-receiving panel from its rear side with aluminum tape or black vinyl tape.

This will also affect the reception of remote control signals. Therefore, set the range to be covered with tape to a range that is problem-free in practice, while checking the reception status.



- 2. Add an interference filter to the front panel of the remote control light-receiving unit.
 - * Lighting equipment that produces strong jamming exists although rarely. Some problems may therefore be unsolvable by managing the air-conditioner side alone.

Effects of the remote control units of other equipment

Checking points

- If, on the remote control unit of a TV or audio equipment, its sound volume key or something similar is left pressed, infrared signals become continuously sent, thereby jamming the reception of remote control signals.
- Check how the remote control unit and related components are stored, thereby checking if there is any possibility that a button may be inadvertently left pressed on the remote control unit of other equipment.

Actions proposed

If there is any such possibility, give explanations to your users to that effect and instruct them to exercise caution.



Effects of other electrical products

Checking points

- · Check the effects of light and power noises coming from other electrical products.
- · Turn on and off the electrical products, turn off the power and turn on the power, and check their effects on the reception of remote control signals.
- · For products whose operating states change, check the effects of each state.

Actions proposed

- · Change the location relationship between the air-conditioner and the target products.
- · Use a different wall outlet for the target products.


Sharing a grounding

Checking points

- · Check for effects of electrical noises coming into the airconditioner through grounding wires.
- Check if the grounding works is for the air-conditioner alone or shared with other equipment. If there is any equipment that shares it, turn on and off that equipment and detach and reattach the power plugs and examine their effects on the reception of remote control signals.



· Establish an independent grounding for the air-conditioner.



Effects of radio waves

Checking points

- · Using a wireless transmitter near the air-conditioner may affect the reception of remote control signals.
- · Have your users try sending signals with a wireless transmitter and examine their effects on the reception of remote control signals.

Actions proposed

- · Add a ferrite core to the power cord and F cable.
- · Add a ferrite core to the internal wiring of the indoor unit.
- · Move the wireless antenna.

Effects of direct sunlight

Checking points

- Direct sunlight and other intense light make the remote control light-receiving unit less sensitive.
- · Check for any time zone where the remote control light-receiving unit of the indoor unit is affected by direct sunlight depending on the location of the sun and mirror reflection.

Actions proposed

· Block the sunlight to protect against direct sunlight.


3. Failure phenomenon: The compressor will not run.

[Situation] The compressor will not run (the same state as the thermometer turned off), the product receives remote control signals normally. The self-diagnosis lamp (LD301) of the outdoor unit blinks once or becomes turned off.

[Estimated failure locations] · Room temperature thermistor, heat exchanger thermistor

· Microcomputer peripheral circuit

[Diagnosis flow] Initiating troubleshooting



4. Failure phenomenon: The fan motor will not stop.


[Estimated failure locations]

- · Indoor fan motor
- · Fan motor drive circuit

[Diagnosis flow]

Initiating troubleshooting

Run the product by remote control and then stop it. (Reproduce the failure phenomenon.) Is the voltage between pins ④ and ⑥ of the fan motor connector (CN2) below 1.5 V? (Take measurements while the failure phenomenon is present.)





Replace the "indoor electrical parts".

5. Timer lamp blinking: blinking once

[Situation] The timer lamp blinks one time and the product will not operate. (This is not a sign of a breakdown.)

[Estimated failure locations] · Reversing valve defective.

The refrigerating cycle block gas leak.

6. Timer lamp blinking: blinking twice

[Situation] The product is giving a display to indicate that it is performing forcible cooling. (This is not a sign of a breakdown.)

7. Timer lamp blinking: blinking three times

[Situation] The timer lamp blinks three times and the product will not operate.

[Estimated failure locations] · Meltdown of the terminal board (the terminal board poorly inserted into the connecting cable)

· Outdoor communication circuit out of order

[Cautions] If a terminal board is replaced to counter the meltdown of the terminal board , ensure

that the connecting cable to be inserted into the terminal board has the appropriate dimension for peeling the insulation sheathing and that the insertion region is

unbent before inserting it into the terminal board securely.

8. Timer lamp blinking: blinking four times

[Situation] The timer lamp blinks four times and the product will not operate.

[Estimated failure locations] · Outdoor unit error.

· Please confirm the times of the LD301 blinking, and then see the outdoor selfcheck lable.


9. Timer lamp blinking: blinking 9 times


Replace the "indoor control P.W.B".

The timer lamp blinks 9 times and the product will not run. [Situation]

[Estimated failure location] • Loose connector, wire break, or short-circuit in the room temperature thermistor or heat exchanger thermistor.

[Cautions] • Starting the product by remote control will initiate failure detection. (Merely turning on the power will not activate the failure detection function.)






10. Timer lamp blinking: blinking 10 times

[Situation] The timer lamp blinks 10 times and the product will not run.

[Estimated failure locations]

- · Loose connector or wire break in the indoor fan motor
- · Indoor fan motor mechanically locked
- · Indoor fan motor
- · Indoor fan motor drive circuit

[Diagnosis flow] Initiating troubleshooting




11. Timer lamp blinking: blinking 12 times

[Situation] The timer blinks 12 times and the product will not run.

- [Estimated failure locations] Erroneous connection in the indoor-outdoor connection line (connecting cable)
 - · Wire break or poor insertion of the indoor-outdoor connection line (connecting cable)
 - Electrical parts in the outdoor unit (communication circuit, power circuit error)
 - · Communication error due to noise in other home electronics
 - *This does not constitute a failure in the air-conditioner

[Cautions] · When lines 1 and 2 of connecting cable are erroneously connected (crossed), the product may not enter self-diagnosis display mode. If the self-diagnosis memory stores data about "timer . lamp blinked 12 times", then, just in case, check if the connecting cable is not erroneously connected




12. Timer lamp blinking : blinking 13 times

[Situation] The timer lamp blinks 13 times and the product will not run.


[Estimated failure location] • EEPROM, microcomputer


[Diagnosis flow]

Replace the "indoor control P.W.B".




128





CHECKING THE REMOTE CONTROLLER



How to run the product with the outdoor unit test switch


If the indoor electrical parts is out of order and if you wish to run the outdoor unit.

- 1. Turn OFF main power supply.
- 2. Connect the Test Switch jig connector to CN18.
- 3. Turn ON the outdoor terminal board L and N (230V AC).
- 4. Confirm that the "LD301" blinks once from the terminal side of the outdoor unit. Afterwards (when about 30 sec elapses after the power turns ON), confirm that the "LD301" changes to blinking 9 times (communication error).
- 5. When the "LD301" is blink 9 times, if you press the Test Switch, the "LD301" lights up.

If you release your finger from the test switch within 1 sec to 4 sec after pressing the switch, the forced cooling operation starts.

X (If you press the test switch for 5 sec or longer, the self-check diagnosis starts. In this case, turn the power off and start the procedure from 1 again.)

- ※(For the initialization of the expansion valve, it may take 1 min until the operation starts).
- 6. When you press the Test Switch again for 1 sec or longer, the unit stops the operation.



RAC-EH18WHLAE/RAC-EH24WHLAE

Self-check

If you cannot judge if it is an abnormality on the electrical part or the compressor by the "Blinking twice, 3 times, 4 times or 5 times" of the self-diagnosis indicator, perform the megger check to check the isolation of the compressor has no problems, perform the following [self-check]. (The inverter should be checked).


How to make the self-check diagnosis

- 1. Turn the power OFF and wait for 10 min or longer.
- 2. Disconnect communication wire indoor outdoor (Terminal pin no. 3).
- 3. Insert external service switch at CN18.
- 4. Turn ON power supply (wait until LD301 9 times blinking).
- 5. Press service switch 5 sec or longer until LD301 blink fast and then release the switch.
- 6. Self-check result will display by LD301 blinking times.

While the test switch has been pressed, the LD301 lights up and, if it is pressed for 5 sec or longer, the LD301 repeats a cycle of "Lighting for 0.2 sec and lights-out for 0.2 sec".

When blinking starts, remove your finger from the test switch.

If you release your finger from the switch below 5 sec, the forced cooling operation starts.




- 7. The result of self-check diagnosis are indicated. The contents of the result of diagnosis are shown in the table below.
- 8. The self-check complete.

Result of the self-check diagnosis

	SELF-CHECK DIAGNOSIS RESULTS				
LD301	Self-diagnosis description	Solution			
Blink 1 time	No problem with electrical parts.	Replace compressor.			
Blink 2 times	Peak current cut signal.	Replace electrical parts.			
Blink 7	Motor current error.	Compressor connector become disconnected. ⇒ Adjust connector.			
times	motor current error.	Compressor connector properly connected. ⇒ Check compressor, then replace electrical parts.			
Blink 10 times	DC voltage error.	Abnormal AC input power supply (outside range of rated voltage ±10%). ► Connect to proper power supply. Normal AC input power supply (inside range of rated voltage ±10%). ► Replace electrical parts.			
Blink 13 times	EEPROM read error.	Replace electrical parts.			

Location of the test switch and LD301



If the judgement results show abnormality, check the connecting wire and, if it is not disconnected, replace the failed parts according to the correcting method.


Cautions

- 1. The self-check is effective only when the power is turned on for the first time. If the LD301 does not lights up, even if the test switch is pressed, turn the power off and wait for 10 min and start the procedure from the beginning.
- 2. After the self-check mode is complete, it is not necessary to turn the power off (normal operation is restored). However, note that the self-check results continue blinking until the compressor starts operating.

***Cautions**

- 1. Before making the connections, be sure to turn off the breaker.
- 2. Do not under any circumstances run the product for more than 5 minutes.
- 3. Doing work with the compressor connector removed will cause the LD301 to blink 4 times. It will not start.
- 4. For another test run, turn off the breaker and turn it back on. (The test switch is accepted only once after power-on. After operation by remote control, it is not accepted.)
- 5. When the operation with the test switch is over, turn off the breaker.

HOW TO OPERATE THE OUTDOOR UNIT INDEPENDENTLY




The operation method is the same as "How to operate using the connector to servicing the outdoor unit". X1 The charging amount of 300g is equivalent to the load in normal operation.

PARTS LIST AND DIAGRAM

INDOOR UNIT

MODEL: RAS-EH18RHLAE




MODEL RAS-EH18RHLAE

NO.	PART NO.		Q'TY / UNIT	PARTS NAME
1	PMS-EH18RHLAE	R01	1	P.W.B (MAIN) (RAS-EH18RHLAE)
2	PMS-EH09PHLAB	R02	1	P.W.B (RECEIVER)
3	PMS-EH18RHLAE	R02	1	CYCLE ASSY
4	PMS-EH09RHLAE	R02	1	FAN MOTOR
5	PMS-EH09PHLAB	R04		FRONT COVER ASSY
6	PMRAS-EH10CKT	R14	1	FRONT PANEL
7	PMS-EH09PHLAB	R05	2	AIR FILTER
8	PMRAS-S18CPA	R02	1	AUTO SWEEP MOTOR
9	PMRAS-EH10CKT	R06	1	TANGENTIAL FAN
10	PMS-EH09PHLAB	R06	1	CABINET
11	PMRAS-25YH4	908	1	P-BEARING ASSY
12	PMS-EH09PHLAB	R07	1	REMOTE CONTROL ASSEMBLY
13	PMRAS-EH10CKT	R19	1	BEARING COVER
14	PMRAS-VX13CET	R10	1	REMOTE CONTROL SUPPORT
15	PMRAS-10C8M	R03	1	THERMISTOR SUPPORT
16	PMRAS-EH10CKT	R07	1	MOUNTING PLATE
17	PMRAS-EH10CKT	R12	1	PIPE SUPPORT
18	PMRAS-EH10CKT	R16	1	S-COVER L
19	PMRAS-EH10CKT	R17	1	S-COVER R
20	PMRAK-50PPD	R07	1	TERMINAL BOARD (3P)
21	PMRAS-XH10CKT	R06	1	THERMISTOR
22	PMRAS-EH10CKT	R09	. 1	H-DEFLECT
23	PMRAS-EH10CKT	R10	1	FM-BASE-L
24	PMRAS-EH10CKT	— R11	1	FM-BASE-R
25	PMRAS-XH10CKT	R07	1	SENSOR ASSEMBLY
26	SPX-CFH22AC25		2	ACL-FILTER
			•	
	_			

PARTS LIST AND DIAGRAM

INDOOR UNIT

MODEL: RAS-EH24RHLAE




MODEL RAS-EH24RHLAE

NO.	PART NO.		Q'TY / UNIT	PARTS NAME
1	PMRAS-VX13CET	R10	1	REMOTE CONTROL SUPPORT
2	PMRAK-50PPD	R07	1	TERMINAL BOARD (3P)
3	PMS-EH24RHLAE	R01	1	P.W.B (MAIN)
4	PMS-EH24RHLAE	R02	1	DRAIN PAN ASSY
5	PMS-SH18RHLAE	R03	2	FILTER
6	PMRAS-10C8M	R03	1	THERMISTOR SUPPORT
7	PMRAS-S50YHAB	R02	1	PWB RECEIVER
8	PMRAS-70YHA4	R04	1	CABINET
9	PMRAS-70YHA4	R05	1	CAP
10	PMRAS-70YHA4	R07	1	CYCLE ASSY
11	PMRAS-70YHA4	R08	1	PIPE SUPPORT
12	PMRAS-70YHA4	R09	1	MOUNTING PLATE
13	PMRAS-70YHA4	R10	1	FRONT COVER ASSY
14	PMRAS-70YHA4	R11	1	FRONT PANEL
15	PMRAS-70YHA4	R12	1	FAN MOTOR BASE
16	PMRAS-70YHA4	R13	1	BEARING COVER
17	PMRAS-X30HGT	R02	1	TANGENTIAL FLOW FAN
18	PMRAS-70YHA4	R15	1	FAN MOTOR SUPP-RS
19	PMRAS-70YHA4	R16	1	FAN MOTOR SUPP-RU
20	PMRAS-70YHA4	R17	1	H-DEFLECT 1
21	PMRAS-70YHA4	R18	1	H-DEFLECT 2
22	PMRAS-25YH4	908	1	P-BEARING ASSY
23	PMRAS-72CHA3	R01	1	AUTO SWEEP MOTOR
24	PMRAS-XH10CKT	R06	1	THERMISTOR
25	PMRAS-VX13CET	R04	1	FAN MOTOR
26	PMRAS-E25YCAB	R01	1	REMOTE CONTROL
27	PMS-EH24RHLAE	R03	1	MS-BOARD
28	SPX-CFH22AC25		2	ACL-FILTER
	_			

PARTS LIST AND DIAGRAM

OUTDOOR UNIT

MODEL: RAC-EH18WHLAE, RAC-EH24WHLAE



MODEL RAC-EH18WHLAE

NO.	PART NO.		Q'TY / UNIT	PARTS NAME
1	KPNT1	001	3	PUSH NUT
2	PMC-EH09WHLAB	S03	1	TERMINAL BOARD(5P)
3	PMC-EH09WHLAB	S10	1	THERMISTOR (OUTSIDE TEMPERATURE)
4	PMC-EH09WHLAB	S11	1	THERMISTOR (DEFROST)
5	PMC-EH18WHLAE	S03	1	SIDE PLATE (R)
6	PMC-EH18WHLAE	S05	1	SV-COVER-B
7	PMC-EH18WHLAE	S06	1	SV-C0VER-T
8	PMC-EH18WHLAE	S07	1	TOP COVER
9	PMC-EH18WHLAE	S01	1	COMPRESSOR
10	PMRAC-25NPA	S02	1	ELECTRICAL EXPANSION COIL
11	PMRAC-25NPA	S03	1	EXPANSION VALVE
12	PMC-EH18WHLAE	S02	1	P.W.B MAIN
13	PMRAC-50NH4	S02	1	CONDENSER
14	PMC-EH18WHLAE	S04	1	STRAINER(COND)
15	PMC-EH18WHLAE	S10	1	STRAINER(PIPE)
16	PMRAC-XH10CKT	S09	1	THERMISTOR (OH)
17	PMC-EH24WHLAE	S09	1	REVERSING VALVE
18	PMRAC-25NH4	S09	1	OVERHEAR THERMISTOR SUPPORT
19	PMRAC-40CNH2	926	1	SIDE PLATE (L)
20	PMRAC-40CNH2	S18	1	SUPPORT (FAN MOTOR)
21	PMRAC-50NH4	S03	1	VALVE 2S -
22	PMRAC-50NH4	S04	1	VALVE 4S
23	PMRAC-50NPD	S07	1	D-GRILL
24	PMRAC-70YHA	S07	1	PROPELLER FAN
25	PMRAC-PH24CLT	S01	1	CABINET
26	PMRAC-X18CD	S04	1	REACTOR
27	PMRAC-XH24CKT	S02	1	FAN MOTOR
28	PMRAM-33NP2B	S06	1	MG-COIL(REVERSING VALVE)

MODEL RAC-EH24WHLAE

NO.	PART NO.		Q'TY / UNIT	PARTS NAME
1	KPNT1	001	3	PUSH NUT
2	PMC-EH09WHLAB	S03	1	TERMINAL BOARD(5P)
3	PMC-EH09WHLAB	S10	1	THERMISTOR (OÜTSIDE TEMPERATURE)
4	PMC-EH09WHLAB	S11	1	THERMISTOR (DEFROST)
5	PMC-EH18WHLAE	S03	1	SIDE PLATE (R)
6	PMC-EH18WHLAE	S05	1	SV-COVER-B
7	PMC-EH18WHLAE	S06	1	SV-C0VER-T
8	PMC-EH18WHLAE	S07	1	TOP COVER
9	PMC-EH24WHLAE	S01	1	COMPRESSOR
10	PMRAC-25NPA	S02	1	ELECTRICAL EXPANSION COIL
11	PMRAC-25NPA	S03	1	EXPANSION VALVE
12	PMC-EH24WHLAE	S04	1	P.W.B MAIN
13	PMRAC-50NH4	S02	1	CONDENSER
14	PMC-EH24WHLAE	S06	1	STRAINER(COND)
15	PMC-EH24WHLAE	S07	1	STRAINER(PIPE)
16	PMRAC-XH10CKT	S09	1	THERMISTOR (OH)
17	PMC-EH24WHLAE	S09	1	REVERSING VALVE
18	PMRAC-25NH4	S09	1	OVERHEAR THERMISTOR SUPPORT
19	PMRAC-40CNH2	926	1	SIDE PLATE (L)
20	PMRAC-40CNH2	S18	1	SUPPORT (FAN MOTOR)
21	PMRAC-50NH4	S03	1	VALVE 2S -
22	PMRAC-50NH4	S04	1	VALVE 4S
23	PMRAC-50NPD	S07	1	D-GRILL
24	PMRAC-70YHA	S07	1	PROPELLER FAN
25	PMRAC-PH24CLT	S01	1	CABINET
26	PMRAC-X18CD	S04	1	REACTOR
27	PMRAC-XH24CKT	S02	1	FAN MOTOR
28	PMRAM-33NP2B	S06	1	MG-COIL(REVERSING VALVE)

HITACHI

RAS-EH18RHLAE / RAC-EH18WHLAE RAS-EH24RHLAE / RAC-EH24WHLAE

PM NO. 0752E

Printed in Malaysia